

INSTRUCTION MANUAL

No. 4

FOR THE

TRIUMPH
Terrier


AND

TRIUMPH
TIGER CUB


TRIUMPH ENGINEERING CO LTD
MERIDEN WORKS · ALLESLEY · COVENTRY · ENGLAND
TELEPHONE MERIDEN 331 TELEGRAMS "TRUSTY COVENTRY"

Ref. 351/57

Published May, 1957



200 c. c. TIGER CUB



150 c. c. TERRIER

INTRODUCTION

The Triumph "Terrier" and "Tiger Cub" have been so designed that the average owner or mechanic will have no difficulty in servicing it if full use is made of this book. The book is written on a purely practical basis and no attempt has been made to introduce the theoretical side.

To the uninitiated we advise that major repairs such as engine and gearbox unit and telescopic fork overhauls are entrusted to a Triumph Dealer who will have the necessary facilities to carry out this type of work.

Each section of the book is headed by a general description. It is then followed by a complete account of the dismantling, examination of the parts and the re-assembly procedure of the unit concerned. We have endeavoured to do this in the most simple form to obviate any difficulties on the part of the operator, who may be a newcomer to motorcycling or not conversant with repair procedure. Each chapter deals with a specific operation (i.e. Dismantling the Engine) which is then broken down into paragraphs and sub-paragraphs. The sequence in which they are broken down is the correct dismantling or assembly procedure. In order not to confuse the operator, sub-assemblies (i.e. cylinder head or flywheel assembly) are dealt with as separate units.

The book is well illustrated with "exploded" and assembled illustrations of the main units which will give the operator a comprehensive view of the internal parts before commencing an operation, and also greatly assist during assembly.

Remember that if essential adjustments are neglected and only casual attention paid to the lubrication and periodical maintenance, the reliability will be affected and in time the servicing costs may be very high.

If additional information is required, first consult the Distributor or Dealer who will always be pleased to assist. Should any difficulty then arise, write to the Triumph Service Department quoting the model type and engine number. These are stamped on the left-hand crankcase, just below the cylinder base flange as shown in the example below.

T 20 — 17101

SERVICE ARRANGEMENTS

CORRESPONDENCE

Technical Advice, Guarantee Claims and Repairs.

Communications dealing with any of these subjects should be addressed to the **SERVICE MANAGER**.

Replacement Parts.

Orders for replacement parts should be addressed to the **SPARES MANAGER**.

In all communications the full engine number complete with all prefix letters and figures should be stated. This number will be found on the L.H. side of the crankcase just below the cylinder flange.

ORDERS

Orders should always be sent to us in the form of a list and not in letter form. Owners are strongly advised to purchase a Spare Parts List so that the correct part numbers can be quoted. These lists contain numerous exploded drawings and cross references which make it very easy to recognise the various parts and are also of great assistance in servicing the model. The specimen order which is printed in the Spare Parts List should be used as a guide.

TECHNICAL ADVICE

Owners will appreciate how very difficult it is to diagnose trouble by correspondence and this is made impossible in many cases because the information sent to us is so scanty. Every possible point which may have some bearing on the matter should be stated so that we can send a useful and detailed reply.

REPAIRS

Before a motorcycle is sent to our Works an appointment must be made. This can be done by letter or telephone. When an owner wishes to return his machine for guarantee repairs, he should first consult his Dealer as we do not normally accept machines in our Repair Shop until the Dealer has inspected them. Frequently the Dealer can overcome the trouble without the delay and expense of sending the machine to the Works. This avoids the machine being out of use for some days when it could be on the road. Where

parts such as cylinders, petrol tanks, etc., are forwarded for repair, they should be packed securely so as to avoid damage in transit. The owner's name and address should be enclosed together with full instructions. In the case of complete motorcycles, a label showing the owner's name and address should always be attached and all accessories such as tools, inflator, handlebar mirrors and other parts removed.

PROPRIETARY FITTINGS

Ancillary equipment which is fitted to our motorcycles is of the highest quality and is guaranteed by the manufacturers and not by ourselves. Any repairs or claims should be sent to the actual maker, or one of their accredited agents who will always give owners every possible assistance. The following are the addresses of the various manufacturers.


Carburettors	Amal Ltd., Holford Works, Perry Barr, Birmingham, 20.
Chains	The Renold & Coventry Chain Co. Ltd., Didsbury, Manchester.
Electrical Equipment	J. Lucas Ltd., Great Hampton Street, Birmingham, 18.
Saddles	Terrys Ltd., 210, Corporation Street, Birmingham. Wright Saddle Co. Ltd., 160, Bristol Street, Birmingham, 5.
Sparking Plugs ...	Champion Sparking Plugs Co. Ltd., Feltham, Middlesex.
Speedometers ...	Smith's Motor Accessories Ltd., Cricklewood Works, London, N.W.2.

TECHNICAL DATA

ENGINE	TERRIER From Engine No. T15/101	TIGER CUB Engine Nos. T20/ 3001 to 16880 and 16983 to 17388
Type	Overhead Valve	Overhead Valve
Number of Cylinders	One	One
B.H.P.	8 at 6000 R.P.M.	10 at 6000 R.P.M.
Bore	2.244" (57 mm.)	2.48" (63 mm.)
Stroke	2.303" (58.5 mm.)	2.52" (64 mm.)
Capacity	9 cu. ins. (149 c.cms.)	12 cu. ins. (199 c.cms.)
Compression Ratio	7 : 1	7 : 1
Valve Clearance (COLD)	0.010" (0.25 mm.)	0.010" (0.25 mm.)
Valve Timing:—		
Inlet opens B.T.C.	30°	30°
Inlet closes A.B.C.	50°	50°
Exhaust opens B.B.C.	55°	55°
Exhaust closes A.T.C.	25°	25°
<i>(Set tappet clearance at 0.015" (0.380 mm.) when timing valves)</i>		
IGNITION		
Distributor Contact Point Gap	0.014" to 0.016" (0.35 to 0.40 mm.)	0.014" to 0.016" (0.35 to 0.40 mm.)
Distributor Range	10°	6°
Sparking Plug Gap	0.022" to 0.025" (0.56 to 0.64 mm.)	0.022" to 0.025" (0.56 to 0.64 mm.)
Sparking Plug Reach	½" (12.7 mm.)	½" (12.7 mm.)
Ignition Timing (Fully Retard):—		
Crankshaft position	8° B.T.D.C.	4° B.T.D.C.
Piston position	¼" (0.4 mm.) B.T.D.C.	at T.D.C.
CARBURETTER		
Type	Amal	Amal
Main Jet	90	100
Needle Jet	0.086" dia. (2.18 mm.)	0.086" dia. (2.18 mm.)
Pilot Jet	20 c.c.	20 c.c.
Needle Position	Middle Groove	Middle Groove
Throttle Valve	4	4
Choke	11/16"	¾"
TRANSMISSION		
Gearbox—Type	Positive Selection foot operated	Positive Selection foot operated
Speeds	Four	Four

Technical Data

Gear Ratios	Overall	Overall
4th—Top	7.13	6.7
3rd—Third	9.5	8.8
2nd—Second	14.85	13.8
1st—Bottom	21.14	20.0
CLUTCH						
Type	Cork in Oil	Cork in Oil
SPROCKET						
Engine	19 teeth	19 teeth
Gearbox	17 teeth	18 teeth
Clutch	48 teeth	48 teeth
Rear Wheel	48 teeth	48 teeth
CHAIN						
Primary (Front)	$\frac{3}{8}'' \times \frac{7}{32}'' \times 62$ link	$\frac{3}{8}'' \times \frac{7}{32}'' \times 62$ link
Secondary (Rear)	$\frac{1}{2}'' \times \frac{3}{16}'' \times 112$ link	$\frac{1}{2}'' \times \frac{3}{16}'' \times 112$ link
CAPACITIES						
Fuel Tank	2 $\frac{1}{8}$ galls. (11.92 litres)	2 $\frac{1}{8}$ galls. (11.92 litres)
Oil Tank	2 $\frac{1}{2}$ pints (1.56 litres)	2 $\frac{1}{2}$ pints (1.56 litres)
Gearbox	$\frac{1}{3}$ pint (200 ccs.)	$\frac{1}{3}$ pint (200 ccs.)
Primary Chaincase	$\frac{1}{2}$ pint (300 ccs.)	$\frac{1}{2}$ pint (300 ccs.)
TYRE SIZE						
Front and Rear	2.75 × 19	3.00 × 19
BRAKES						
Type	Internal Expanding	Internal Expanding
Drum Diameter	5 $\frac{1}{2}$ '' (13.97 mm.)	5 $\frac{1}{2}$ '' (13.97 mm.)
SUSPENSION						
Front	Telescopic	Telescopic
Rear	Plunger	Plunger
OVERALL DIMENSIONS						
Seat Height	28 $\frac{1}{2}$ '' (71.8 cms.)	30'' (76.2 cms.)
Wheel Base	49'' (124.5 cms.)	49'' (124.5 cms.)
Length	77'' (195.5 cms.)	77'' (195.5 cms.)
Width	25'' (63.5 cms.)	25'' (63.5 cms.)
Ground	5'' (12.7 cms.)	5'' (12.7 cms.)
WEIGHT						
Unladen	175 lbs. (79.4 kilos)	182 lbs. (82.5 kilos)



LATER MODEL 200 c.c. "TIGER CUB"

Engine Nos. 16881 to 16982 and 17389 onwards.

SPECIFICATION VARIATIONS

TRANSMISSION

Gear Ratios.

4th—Top	6.35
3rd—Third	8.35
2nd—Second	13.1
1st—Bottom	19.0

SPROCKETS

Engine	18
Gearbox	17
Clutch	36
Rear Wheel	54

CHAINS

Primary (Front)	$\frac{1}{2}'' \times \frac{3}{16}'' \times$ 48 links
Secondary (Rear)	$\frac{1}{2}'' \times \frac{3}{16}'' \times$ 116 links

CAPACITIES

Fuel Tank	3 $\frac{1}{8}$ galls. (14.2 litres)
-----------	-----	-----	-----	-----	-----	-----	-----	--------------------------------------

TYRE SIZE

Front and Rear	3.25 x 16
----------------	-----	-----	-----	-----	-----	-----	-----	-----------

OVERALL DIMENSIONS

Seat Height	29" (73.7 cm.)
Length	76" (193 cm.)
Ground Clearance	4" (10.2 cm.)

WEIGHT

Unladen	205 lbs. (94.1 kilos)
---------	-----	-----	-----	-----	-----	-----	-----	-----------------------

TYRE PRESSURES

Front	18 lbs/sq. in. 1.265 Kg/sq. cm.
Rear	20 lbs/sq. in. 1.40 Kg/sq. cm.

All other dimensions as on Pages 6 and 7.




Fig. 1. CONTROL LAYOUT

CONTROLS

The position and application of the controls is explained by assuming that the rider is sitting on the machine.

HANDLEBAR

Clutch Lever. On the left portion of the handlebar. The clutch lever should not be operated when the machine is in motion except to change gear and when bringing the machine to a halt.

Front Brake Lever. On the right portion of the handlebar. Always apply gentle pressure to the lever and use in conjunction with the rear brake.

Throttle Control. This is twistgrip operated by the right hand. Twist the grip towards you to open and away from you to close.

Horn Button. Fitted in the left portion of the handlebar. Push to operate.

Head Lamp Dipper Switch. Clipped to the right handlebar. Depress or raise switch lever to operate.

NACELLE PANEL

Speedometer. Registers speed and total mileage.

Lighting Switch. Turn the lever to operate. Switch positions:—

OFF	...	ALL LIGHTS OFF
L	...	TAIL AND PARKING LIGHTS ON
H	...	TAIL AND HEADLIGHT ON

Ignition Switch. Operated by a key. Switch positions:—

CENTRAL	IGNITION OFF
"IGN"	IGNITION NORMAL
"EMG"	IGNITION EMERGENCY

Gear Indicator. The indicator is centrally disposed and shows the gear selected by the rider when the gearchange pedal is depressed or raised.

FOOT CONTROLS

Foot Brake. A flat pedal in front of the left footrest. Depress to operate. The first application should be applied gently and then the pressure increased as the road speed decreases.

Gearchange. A small foot lever in front of the right footrest. The lever is moved DOWN to select a low gear and UP to select a higher gear. The gear selected is indicated by a small indicator lever on the nacelle panel.

Kickstarter. This pedal is behind the right footrest. (See below for starting the engine).

TAKING OVER THE MACHINE

After taking delivery of the machine and before taking it on the road, carefully check that the oil tank, primary chaincase and gearbox oil levels are correct (see page 7). The tyres should be checked with a pressure gauge and if necessary adjusted in accordance with the instructions on page 87. Re-fill the petrol tank with 80-octane fuel and the machine is ready for starting.

Although each machine is thoroughly checked before leaving the works for the security of all nuts and bolts, it is advisable after the first 100 miles to re-check, and again at 500 miles. This is a necessary precaution due to the bedding down of the engine and motorcycle parts.

STARTING THE ENGINE (COLD)

1. Select the neutral gear position "N". Indication is by the gear indicator on the nacelle.
2. Lift the clutch lever and depress the kickstarter two or three times to separate the clutch plates.
3. Turn on the petrol by turning the petrol tap lever into the vertical position. Depress the tickler on the top of the carburettor float bowl until the lower part of the mixing chamber shows a seepage of petrol. Over flooding will cause very difficult starting. Close the air slide if the temperature is low.

4. Fit the ignition key to the nacelle switch and turn clockwise to position "IGN", this being the normal IGNITION position.
5. Depress the kickstarter when the engine should fire immediately.
6. If, due to a flat battery there is insufficient spark to start the engine, turn the ignition key anti-clockwise to position "EMG" which is the EMERGENCY start position.
7. Again depress the kickstarter when the engine will fire.
8. **Once the engine is running, the ignition key must be returned to position "IGN" (IGNITION). The engine should not be run in the "EMERGENCY" position longer than is absolutely necessary unless the negative lead to the battery is earthed to the frame (see page 94). Open the air slide immediately the engine starts.**

PARKING

Always remove the key from the ignition switch and turn off the petrol when parking the machine.

RUNNING-IN

These machines, although of small engine capacity, have an exceptional performance and therefore the rider must curb his natural desire to test its capabilities during early life. Previously, motorcyclists have been advised not to exceed certain speeds on the various gears, but with the modern machine this type of running-in is entirely useless, and at the end of the first 1,000 miles very little improvement will have been effected on the bearing surfaces of engine and gearbox unit.

Running-in should be carried out progressively; the main essential is to avoid large throttle openings. Never at any time stress the engine by overloading in the higher gears or overdriving in the lower gears. The engine has ample power to cope with all conditions if the gearbox is correctly used.

Lubrication System

The machine should be run-in for 1,000 miles; during the first half of the running-in period, do not exceed $\frac{1}{2}$ throttle opening for more than a limited time. Occasional bursts of speed will greatly assist the bedding down process but if sustained can only result in disaster. After this period the throttle opening can be increased gradually until the maximum power output can be put into operation.

During the early period of the machine's life the owner is advised to change the engine and gearbox oil at the periods stated on page 27.

Remember that if these instructions are carried out intelligently, the machine will be mechanically quieter, wear longer and maximum power will be available.

LUBRICATION SYSTEM

ENGINE

Dry sump lubrication is employed. The system is operated by a twin plunger reciprocating oil pump driven by an eccentric spindle on the distributor shaft. The plungers are of different diameters, the smaller being the pressure side, the larger the scavenge. As the scavenge side has the larger capacity, the crankcase is kept free of oil. The feed to the oil pump is from a gravity oil tank via a filter and oil pipe. The oil pump is provided with non-return valves to prevent crankcase flooding. The scavenge pipe is located in the base of the crankcase and can be observed after removal of the crankcase base plug. The excess oil filters through a gauze and is returned to the oil tank via the crankcase pipe, oil pump and external pipe.

A positive oil feed to the crankcase timing side plain bearing and big-end is maintained and, with the exception of the rocker spindles, the remainder of the engine is lubricated by oil splash. The rocker spindle feed is from the scavenge side of the system. The rocker feed pipe is tapped into the scavenge pipe at the bottom of the oil tank and the oil is then forced (scavenge pressure) through the pipe and to the hollow rocker spindles. The surplus oil then lubricates the valves, push rods and rocker ball pins and finally drains through holes in the cylinder head and barrel to the crankcase.




Fig. 2. LUBRICATION DIAGRAM

GEARBOX

Although the engine and gearbox are one unit, both have their separate oiling systems. Oil is fed into the gearbox casing via the filler plug and all gears, bushes and bearings are lubricated by splash.

PRIMARY CHAINCASE

The clutch and alternator are both designed to operate in oil and the case must therefore always contain an adequate amount of lubricant.

MAINTENANCE OF LUBRICATION SYSTEM

ENGINE

The lubrication system is extremely simple and gives long service without attention. Precautions such as changing the oil at the right time should be observed, cleaning the oil filters and using the recommended lubricants. Proof of the oil system working is to remove the oil tank filler cap, then start the engine and observe the return of oil to the oil tank. This should be intermittent due to the fact that the scavenge side of the pump has more capacity than the feed. The oil will spurt for a few minutes and then be followed by air bubbles.

In the event of a lubrication fault the following causes have been listed to assist in diagnosing the trouble:—

Oil Tank. The amount of oil in the tank should be within 1" (2.5cm.) of the filler cap. Further addition of oil will cause excessive venting through the oil tank vent to the air filter, due to lack of air space. Always ensure that the oil tank vent hole is clear, otherwise the air pressure will build up in the tank and prevent adequate scavenging by the oil pump resulting in an oil flooded crankcase.

Complete Lack of Scavenge. There are various reasons for this and the explanations are divided under the following headings in the order in which they may arise.

(a) **Stoppage in the External Scavenge Pipe.** This can be caused by a piece of rubber detaching itself from the rubber connector or a piece of foreign matter lodged in the oil block. To remedy, remove the oil pipe assembly and blow through with a tyre pump or if available an air line. Also check the stack pipe in the oil tank. If all is in good order suspect oil pump.

(b) **Oil Pump.** To remove this unit for inspection, the outer and inner timing covers will have to be removed (See Engine Dismantling, page 35). Remove the two oil pump securing bolts and withdraw the assembly from the housing. Collect the two balls and springs from behind the pump. (See Page 112). Dismantle the pump by taking out the plungers and unscrewing the two base plugs. Under the plugs are the springs and balls. If any foreign matter gets between the ball and seating, the pressure feed or scavenge as the case may be, will, of course, be affected. When dismantling, therefore, handle the parts carefully so that any foreign matter on the balls or seatings can be located and the cause of the trouble ascertained. After making sure that the pump is clear of foreign matter, wash all parts thoroughly and then make the following inspection.




Fig. 3. OIL PUMP IN POSITION

Maintenance of Lubrication System

(b1) **Connecting Link.** Inspect the drive hole for ovality as this will affect the stroke of the plungers resulting in inadequate feed and scavenge.

(b2) **Connecting Link Pin.** This should be a tight fit in the connecting link and a working fit in the plungers.

(b3) **Plungers.** Normally the plungers will show negligible signs of wear. If wear is in evidence the engine will have been starved of oil, resulting in excessive wear and overheating, and maybe inadequate scavenging.

(b4) **Pump Body.** The seatings of the non-return balls should be examined and if there is any signs of indentation on the seats they should be re-cut with a 45° cutter. Only a minimum amount of metal should be removed.

(b5) **Balls.** These should be inspected before replacing and if any sign of pitting is in evidence, replace with new balls.

(b6) **Ball Valve Springs.** If these are unduly fatigued they should be discarded and replaced with new ones.

(c) **Oil Pump Assembly.** When fitting the ball valves into the pump body it is advisable to give them a sharp tap onto the seatings, using an aluminium punch as a medium. When this is done, replace the springs and screw in the base plugs. Oil the plungers and attach the connecting pin (circlip in the top position) and drive rod, then assemble to the body. To check the action of the pump, submerge in oil and operate the plungers carefully; oil should be expelled from the pressure side with considerable force. Stick the auxiliary balls to the pump body with a smear of vaseline. (See Page 112). The pump is now ready for assembly to the engine. Always ensure the correct fitting of the joint washer, i.e. matching the oil holes.

(d) **Crankcase Scavenge Pipe.** In the unlikely event of this cracking, or an air leak between the pipe and the crankcase, the oil will not scavenge from the crankcase. Trouble of this kind would only make itself known when the engine is hot. A simple test is to fit a piece of rubber tubing over the scavenge pipe, then place

the rubber tube in the mouth and suck. If the rubber tubing collapses this proves the scavenge pipe joints etc. are air tight; on the other hand if the tube does not collapse, a leakage is evident. Always make this fault the last suspect.

Engine Overheating due to Lack of Oil. The following reasons are listed in the order in which they may arise.

(a) **Oil Tank.** Check oil level and top up if the oil is below the minimum level. Remove the filter and clean. If the oil has a heavy deposit of sludge, remove the oil tank and thoroughly clean out.

(b) **Stoppage in the External Feed Pipe.** Remove and clean out (See page 17, paragraph (a)).

(c) **Oil Pump.** See page 17, paragraph (b).

NOTE.—Always use the correct grade of oil as recommended on pages 106 and 107. Cheap, inferior, or the incorrect grade of oil will shorten the life of the engine.

CHANGING THE OIL

When the machine is new the oil should be changed frequently during the running-in period. The best time to do this is after a run when the oil is hot, then any foreign matter which the oil picks up in the course of its circulation is expelled during the draining.

Engine and Gearbox Unit. Change the oil at 250, 500 and 1,000 miles during the running-in period and thereafter as laid down on page 27, "Routine Maintenance". The following procedure should be adopted:

(a) **Engine.** Remove the sump plug, filter and light spring, and drain the oil into a receptacle.

(b) **Oil Tank.** Pull the oil pipes out of the rubber connections beneath the oil tank.

Changing the Oil

(c) **Oil Tank Filter.** Unscrew from oil tank and inspect the inside of the tank. If not thoroughly clean, wash out with flushing oil.

(d) **Cleaning.** Wash all parts and blow out with air to ensure that all oil ways are clean. Re-assemble the parts to the engine and oil tank and replenish with fresh oil. Replace engine fixing bolt.

(e) **Gearbox.** Remove the drain and level plug assembly and allow the oil to drain. With machine off the stand and the drain plug replaced, replenish with fresh oil until the oil seeps out of the drain plug, when the oil level will be correct. Replace the level plug into the body of the drain plug.

(f) **Primary Chaincase.** Remove the drain plug and allow the oil to drain. Replace the plug and then remove the level and filler plugs in the chaincase. Pour oil into the chaincase until it seeps from the level plug. Replace both plugs.




Fig. 4. CHECKING TAPPET CLEARANCE

TAPPET ADJUSTMENT

Tappet adjustment is made on the rocker arms after removing the inspection covers (See Fig. 4). The adjustment must always be carried out when the engine is COLD, never at any time make an adjustment immediately after using the machine.

Before making an adjustment, it must be ascertained that the tappet is NOT resting on the cam ramp. To do this and make the adjustment, proceed as follows:—

(a) Place the machine on the central stand and then engage TOP gear.

(b) **Sparking Plug.** Remove from the cylinder head.

(c) **Inspection Covers.** Remove both inlet and exhaust covers.

(d) **Piston and Valve Positioning.** To position these parts correctly, turn the engine by rotating the rear wheel until the INLET VALVE CLOSSES and the piston reaches the TOP of its stroke. The true top dead centre can be ascertained by just moving the rear wheel in both directions and feeling the top of the piston with a wire rod.

(e) **Making the Adjustment.** Slacken off the adjuster pin locknut, then turn the adjuster until a 0.010" (0.25 mm.) feeler can be inserted between the tip of the valve and the adjuster head. Tighten up the locknut and re-check the clearance. When the locknut is tightened the clearance is sometimes affected, therefore a second adjustment may have to be made. The feeler gauge must slide freely between the two parts.

Always carry out the operation with the utmost care as incorrectly adjusted valves will cause:—

- Lack of power
- Bad starting
- Noisy engine
- Poor petrol consumption
- Burnt valves

ADJUSTING THE BRAKES

Place the machine on the stand and test the front brake first.

Front Brake. The brake shoe adjustment is made by turning the adjuster in the brake cable which is situated in the clip on the right hand telescopic fork member. Slacken the locknut and turn the adjuster anti-clockwise to bring the brake shoes into closer contact with the brake drum. Spin the wheel after making the adjustment to ensure that the brake shoes are not binding. The illustration below shows the adjuster and the correct lever position.




Fig. 5. FRONT BRAKE ADJUSTMENT

The shadow lined brake lever indicates the position when the brake linings are worn badly. The normal position shows that the linings are in good order.

Rear Brake. The brake shoe adjustment is made by turning the thumb nut at the rear end of the brake operating rod. To take up wear, turn the nut in a clockwise direction. Spin the wheel after making the adjustment to check freedom of movement. See the illustration below for further details.




Fig. 6. REAR BRAKE ADJUSTMENT

The shadow lined brake lever indicates the position when the brake linings are worn badly. The normal position shows that the linings are in good order.

CHAIN ADJUSTMENT

PRIMARY CHAIN

The primary chain is on fixed centres in a fully enclosed oil bath and therefore requires no adjustment. The free movement in the chain will increase very slowly due to wear, but it is not harmful and it is unnecessary to replace the chain until the lower run touches the bottom of the chaincase.

REAR CHAIN

This chain is adjusted by the two adjusters fitted to the rear wheel spindle and rear suspension fork ends. Adjustment is made by first slackening off the wheel spindle nuts and then turning the adjuster nuts. Particular care should be taken when carrying out this operation not to disturb the alignment of the wheels; always ensure an equal number of turns each side when making the adjustment.

After making an adjustment, check the chain whip midway between the two sprockets, this should be $\frac{3}{8}$ " (9.5 mm.) to $\frac{1}{2}$ " (12.7 mm.) on the lower run. Turn the rear wheel and check the chain at several points until the chain has made one revolution. This operation is necessary as the chain wear is sometimes not even and there is usually a position in the chain which is tighter than elsewhere.

There is an automatic oil feed to the rear chain from the crankcase breather, but it is recommended that the chain is removed for cleaning and re-lubricating at the periods shown on page 27.

Successive baths of clean paraffin should be used until the chain is quite clean and free from grit. The chain should be allowed to drain and then placed in a bath of molten graphite grease. The chain should be allowed to remain in the grease until it has cooled off and become solid again, as, if it is just dipped in and removed, the grease may not penetrate underneath the rollers and much of it will drain away. When the chain is removed, surplus grease should be wiped off it and it should be re-fitted and adjusted. When fitting the spring fastener on the removable link, care should be taken to place it in the correct position. The spring fastener is roughly the shape of a fish, and if it is remembered that a fish swims nose first, and the fastener fitted so that the nose is always proceeding

In the forward direction when the machine is running, the fitter will have an easy aid to memory. Chains give very large mileages if carefully used, but no part of a motorcycle shows more quickly the result of neglect and abuse. As chains are comparatively expensive, proper maintenance will assist in the economical operation of the machine.

ALTERATION AND REPAIRS

If the chains have been correctly serviced, very few repairs should be necessary. Should the occasion arise to repair, lengthen or shorten a chain, a rivet extractor and a few spare parts will cover all requirements.

To **SHORTEN** a chain containing **AN EVEN NUMBER OF PITCHES** remove the dark parts shown in Fig. 7 and replace by cranked double link and single connecting link as Fig. 8.



Fig. 7



Fig. 8

To **SHORTEN** a chain containing an **ODD NUMBER OF PITCHES**, remove the dark parts shown in Fig. 9 and replace by single connecting link and inner link as Fig. 10.



Fig. 9



Fig. 10

To **REPAIR** a chain with a broken roller or inside link, remove the dark parts in Fig. 11 and replace by two single connecting links and one inner link as Fig. 12.



Fig. 11



Fig. 12

RIVET EXTRACTOR

The rivet extractor can be used on all motorcycle chains up to $\frac{3}{4}$ " pitch, whether the chains are on or off the wheels. When using the extractor:—

1. Turn screw anti-clockwise to permit the punch end to clear the chain rivet.
2. Open the jaws by gripping tommy bar and handle together (see Fig. 13).
3. Pass jaws over chain and release grip. Jaws should rest on a chain roller free of chain link plates (see Fig. 14).
4. Turn screw clockwise until punch contacts with and pushes out rivet end through chain outer link plate. Unscrew punch, withdraw extractor and repeat complete operation on adjacent rivet in the same chain outer link plate.




Fig. 13




Fig. 14

rivet end through chain outer link plate. Unscrew punch, withdraw extractor and repeat complete operation on adjacent rivet in the same chain outer link plate.

ROUTINE MAINTENANCE AFTER RUNNING-IN PERIOD

ENGINE	<i>Miles.</i>	<i>Kilos.</i>
Check oil and replenish if necessary ...	250	400
Drain oil tank (oil hot) and re-fill ...	1,500	2,400
Clean oil filters	1,500	2,400
Tappets—Check and adjust if necessary...	3,000	4,800
Sparking plugs—Clean and adjust ...	3,000	4,800
Decarbonise	8,000-10,000	12,800-16,000
 GEARBOX		
Check oil and replenish if necessary ...	1,000	1,600
Drain oil (oil hot) and re-fill	5,000	8,000
 PRIMARY CHAINCASE		
Drain oil (oil hot) and re-fill	1,000	1,600
Check cover security screws	1,000	1,600
 FORKS		
Grease	4,000	6,400
Renew bushes	20,000	32,000
Grease headraces	10,000	16,000
Check headrace adjustment	5,000	8,000
 REAR SUSPENSION		
Grease	1,000	1,600
 WHEELS		
Re-pack with grease	10,000	16,000
Brake cam spindle (do not over grease) ...	2,000	3,200
 CHAIN (Rear)		
Adjust tension	1,500	2,400
Lubricate (Winter) see Page 24	1,000	1,600
Lubricate (Summer) see Page 24	1,500	2,400
 BRAKES		
Grease cable and rod mechanism	1,000	1,600
Adjust (normal)	1,000	1,600

Routine Maintenance

OPERATING CABLES

	<i>Miles.</i>	<i>Kilos.</i>
Lubricate with oil	2,500	4,000

DISTRIBUTOR

Lubricate with thin oil	5,000	8,000
Adjust contact points	5,000	8,000

BATTERY

Top up monthly

TYRE PRESSURES

Check and correct weekly (see Page 87)

CARBURETTER

Dismantle and clean	1,500	2,400
----------------------------	-------	-------

AIR FILTER

Clean and re-oil element	2,000	3,200
---------------------------------	-------	-------

(When the machine is in use on extremely dusty conditions, the servicing period should be at more frequent intervals).

GENERAL

Check cable wires for fraying, nuts and bolts, cables etc. for security ...	1,000	1,600
---	-------	-------

**SEE PAGES 106 AND 107 FOR
RECOMMENDED LUBRICANTS
AND
PAGES 108 AND 109 FOR
LUBRICANT CHART**

DECARBONISING

DISMANTLING

Before commencing this operation, first clean the engine and gear-box unit with paraffin or a suitable degreasing agent. Secondly, obtain two boxes, one large enough to take the cylinder barrel, cylinder head etc., and the other need only be a small container for the nuts, washers, etc. By doing this the operator will not have to search the four corners of the garage for the vital nut to complete the job.

Now set out the requisite tools necessary to dismantle the engine on a clean sheet of brown paper. Finally, obtain a Gasket Set before dismantling. Commence to dismantle in the following manner:—

1. **Exhaust System.** Slacken the bolt in the exhaust pipe to cylinder head clip and remove the silencer to frame bolt; take away the exhaust system.
2. **Engine to Frame Bolts.** Remove the two front bolts and slacken the rear engine to frame bolt to obtain sufficient clearance to detach the cylinder head.
3. **Rocker Oil Feed Pipe.** Disconnect by removing the rocker spindle nuts and easing the pipe banjo unions over the spindles.
4. **Carburetter.** Unscrew the petrol feed pipe at the tap, remove air cleaner rubber connection and then remove the joint flange nuts and washers. Withdraw carburetter off the studs and allow to hang on the cable. Should the carburetter require cleaning, unscrew the knurled ring securing the throttle and air slides and take away the mixing chamber and float bowl leaving the slide still attached to the operating cable.
5. **Cylinder Head.** Unscrew the "Simmonds" nuts securing valve tappet covers to cylinder head and remove covers. Remove the sparking plug and the four cylinder head holding nuts and ease the head away from the cylinder barrel. Do not attempt to prise the head from the barrel by placing a screwdriver between the fins,

Decarbonising

as damage to the finning is almost sure to occur. Should the separating of these parts prove difficult, gently tap the area round the rocker box with a hide hammer when the joint will be broken.

6. **Push Rods and Cover.** Withdraw the pushrods and raise the cylinder barrel to remove the cover tube.

7. **Cylinder Barrel.** This simply lifts over the long studs but should the operator suspect piston ring failure, it is advantageous partially to lift the barrel only and then fill the crankcase aperture with clean cloth to avoid any broken rings falling into the crankcase.

8. **Piston.** Remove a circlip and press the gudgeon pin out from the opposite end, the piston assembly can now be removed from the connecting rod. Mark the inside of the piston in order to identify the front and rear when replacing.

REMOVING THE CARBON AND PREPARATION OF UNITS FOR RE-ASSEMBLY

A fully detailed account will be found on page 39, which explains the method of dismantling, rectifying and re-assembly of the units.

RE-ASSEMBLY

Piston. To assemble the piston, first replace one circlip and ensure that it fits well into the gudgeon pin boss groove, then assemble the piston rings, first the scraper ring and then the two compression rings. Well oil the piston rings and make sure that they revolve freely in the grooves. Oil the gudgeon pin and assemble to the piston so that it just protrudes through the boss opposite to the one already fitted with the circlip. It is now ready for assembly to the connecting rod. Identify the front of the piston and then place it over the rod and enter the gudgeon pin through the small end bush and into the piston boss until the pin contacts the circlip. Fit the remaining circlip, making sure of the fit in the groove.

Cylinder Barrel. Clean and oil the bore and fit the base washer to the flange, grease to hold in position. Place the piston in the position shown in Fig. 15, and assemble the cylinder barrel to the crankcase. Fit the copper gasket to the cylinder barrel top flange.

Push Rods and Cover. Fit the sealing washers to the cover tubes, top—SILICONE RUBBER (CREAM), bottom—RUBBER. Raise the cylinder barrel sufficiently to enable the fitting of the cover tube to the crankcase. Replace the push rods and engage to the tappets; check the action by turning the engine mainshaft.




Fig. 15

Method of supporting the piston when replacing the cylinder barrel

Cylinder Head Assembly. First correctly position the push rods in relation to the cylinder head rocker gear. The INLET push rod is the OUTER and the EXHAUST push rod is the INNER, (looking at the engine from the RIGHT HAND side). Lower the cylinder head complete with exhaust fin clip onto the cylinder barrel engaging the push rods to the respective rocker ball ends. Fit the four sleeve nuts and before finally tightening, check the valve action by turning the engine. Tighten down the nuts evenly.

Engine to Frame Bolts. Replace the bolts and ensure the nuts are well tightened.




Fig. 16. Positioning the Push Rods

Rocker Feed Pipe. Fit a copper washer to each rocker spindle and then replace the feed pipe, followed by a further two copper washers and two dome nuts. Care should be taken not to overtighten the nuts, otherwise the pipe may turn and break at the banjo unions.

Carburetter. Replace this unit in the reverse manner to the dismantling procedure and should the air cleaner rubber connection seem perished in any way it should be replaced by a new one. Check operation of throttle control after assembly, the action should be free and the throttle valve should fall to the fully closed position.

Exhaust System. Replace the pipe and silencer and tighten the exhaust fin clip and silencer bolt.

Valve Tappet Cover. First turn to page 21, where adjustment of the valve tappet is fully described, then adjust the tappets. Lubricate the valve gear by applying oil with an oil gun or if not available, bend a piece of tin and pour the oil in. Replace the valve tappet covers with the new joint washers and finally tighten down the nuts.

Sparking Plug. Replace and attach the H.T. lead. It is advisable to graphite grease the threads of the plug before fitting; do not overtighten.

The engine is now ready for starting. After running for a short period stop the engine and re-check and tighten, if necessary, all engine nuts.

OVERHAULING THE ENGINE AND GEARBOX UNIT

Removing the Engine from the Frame

Before commencing this operation the operator is advised to remove the petrol tank. This operation is not entirely necessary as the engine can be removed without disturbing the tank, but on the other hand it simplifies the removal of control cables and prevents possible damage to the tank.

Chainguard. Remove the two bolts, guard to crankcase and mudguard stay. Then remove the nut, screw and distance piece securing chainguard to mudguard. Withdraw chainguard.

Exhaust System. Slacken the bolt in the exhaust pipe clip, remove the silencer bolt and take off the exhaust system.

Control Cables. Disconnect all engine and gearbox cables at the handlebar. Free them from the frame cable clips.

Brake Pedal and L.H. Footrest. Remove the nuts securing these parts and withdraw from the spindles.

Oil Feed and Scavenge Pipes. Place an oil tray under the engine. Remove the lower front engine to frame bolt and detach the oil pipe junction block. To drain the oil more quickly, disconnect the pipe from the oil tank.

Rocker Oil Feed Pipe. Remove the two rocker spindle nuts, and ease the banjos off the spindles.

Electrical Connections. Disconnect cables to distributor and sparking plug.

Engine Bolts. Remove the two remaining engine to frame bolts. Drop the engine at the rear and raise at the front, then remove the unit from the L.H. side (drive side) of the machine.

DISMANTLING THE ENGINE AND GEARBOX UNIT

Distributor. Slacken the distributor clip and withdraw the unit from the crankcase.

Carburetter. Remove the two securing nuts and withdraw carburetter and insulating block.

Drive Side Cover. Remove the securing screws and gently tap the cover away from the crankcase.

Clutch, Engine Sprocket and Rotor. First unscrew the three clutch nuts and remove pressure plate. Bend back the clutch locking plate tab and undo clutch to mainshaft locknut. Remove the engine mainshaft locknut and withdraw the rotor and distance piece. Screw into the clutch centre the extractor (Part No. Z95) and tighten the extractor bolt to release the clutch from the taper mainshaft. Remove the rotor key and then withdraw the clutch, engine sprocket and chain as one unit. Tap the clutch key out of the gearbox mainshaft.

Kickstarter and Footchange Pedal. Remove the nut from the kickstarter cotter, turn the pedal to the horizontal position and drive the cotter out. One good sharp blow with a hammer will usually free it. Remove the pedal from the shaft. Unscrew and remove the footchange pedal screw and withdraw the pedal from the splined shaft.

Timing Side Cover. Take out the securing screws and tap the cover away from the inner cover.

Kickstarter Spring and Anchor Plate. Carefully ease the anchor plate off the spindle. To prevent any injury, hold a piece of rag over the plate. Remove the spring from the casing.

Timing Side Inner Cover. First remove the small metal plate held by two screws, then take out the split pin which secures the camplate to the spindle and take out the spindle. Remove the four screws and withdraw the cover. To prevent any misalignment of the distributor-oil pump shaft bush, replace the appropriate screw.




Fig. 17

ENGINE AND GEARBOX UNIT

In order to clarify the main components, the screws and washers etc. have been omitted from this illustration. For clutch details see Fig. 28, page 61.

INDEX TO FIG. 17.

Index No.	Description.	Index No.	Description.	Index No.	Description.	Index No.	Description.
1	Barrel, cylinder.	39	Washer, cover joint (upper).	77	Plunger, oil feed.	113	Spring, gear selector plunger.
2	Washer, cylinder base.	40	Washer, cover joint (lower).	78	Rod, oil pump drive.	114	Spring, pedal return.
3	Piston.	41	Tapet.	79	Pin, oil pump drive.	115	Pin, return spring anchor.
4	Ring, top compression.	42	Nut, oil pipe to rocker spindle.	80	Ball, oil pump valve.	116	Bearing, gearbox sprocket (ball).
5	Ring, middle taper.	43	Washer, oil pipe nut.	81	Spring, oil pump valve.	117	Oil seal, (felt) sprocket bearing.
6	Ring scraper.	44	Washer, oil pipe nut.	82	Plug, oil pump body.	118	Plate, oil seal retaining.
7	Pin, gudgeon.	45	Flywheel assembly, L.H.	83	Spring, auxiliary valve.	119	Bush, gearbox layshaft L.H.
8	Circlip.	46	Flywheel assembly, R.H.	84	Ball, auxiliary valve.	120	Kickstarter, folding.
9	Head, cylinder.	50	Rod, connecting.	85	Sprocket, engine.	121	Cotter, kickstarter.
10	Gasket, cylinder head.	51	Bush, big end.	86	Distance piece, sprocket and rotor.	122	Spindle, kickstarter.
11	Adaptor, exhaust pipe.	52	Bush, small end.	87	Nut, sprocket and rotor.	123	Pawl, kickstarter.
12	Stud, rocker cover.	53	Crankpin.	88	Cover, L.H. inner.	124	Plunger, kickstarter.
13	Stud, carburettor.	54	Circlip, drive pin.	89	Cover, L.H. outer.	125	Spring, kickstarter plunger.
14	Nut, head to barrel.	55	Crankcase assembly.	90	Bearing L.H. main (ball).	126	Spring, kickstarter return.
15	Valve.	56	Stud, head to crankcase.	91	Plug, oil lever.	127	Plate, kickstarter return.
16	Guide, valve.	57	Stud, oil pipe junction block.	92	Washer, level plug.	128	Plate, kickstarter stop.
17	Circlip, valve guide.	58	Dowel, inner cover to crankcase.	93	Washer, level plug.	129	Screw, kickstarter stop.
18	Spring, valve inner.	59	Pipe, crankcase oil return.	94	Cover, R.H. inner.	130	Sprocket, gearbox.
19	Spring, valve outer.	60	Washer, L.H. outer cover joint.	95	Bush, camshaft outer.	131	Nut, gearbox sprocket.
20	Collar, valve spring top.	61	Bolt, oil return pipe.	96	Bush, gearbox mainshaft.	132	Plug, gearbox filter.
21	Collar, valve spring bottom.	62	Bearing, R.H. (plain).	97	Plate, gearbox inner cover.	133	Washer, filter plug.
22	Cotter, valve split.	63	Bush, camshaft inner.	98	Washer, inspection plate joint.	134	Plug, gearbox drain.
23	Rocker, valve.	64	Bush, distributor and oil pump shaft.	99	Cover, R.H. outer.	135	Washer, drain plug.
24	Ball, pin rocker.	65	Filter, crankcase.	100	Layshaft gear cluster.	136	Plug, gearbox level.
25	Adjuster, rocker.	66	Spring, crankcase filter.	101	Key, clutch to mainshaft.	137	Washer, level plug.
26	Locknut, rocker adjuster.	67	Cap, crankcase filter.	102	Fork, gear selector.	138	Clutch.
27	Spindle, valve rocker.	68	Washer, filter cap joint.	103	Spindle, selector fork.	139	Lever, clutch operating.
28	Sealing ring, rocker spindle.	69	Pinion, timing and distributor drive.	104	Camplate, gearbox.	140	Ball, cup to rod.
29	Thrust washer, rocker spindle.	70	Bolt, timing pinion.	105	Spindle, camplate.	141	Rod, clutch operating.
30	Thrust washer, rocker spindle.	71	Pinion, camshaft.	106	Spring, camplate locating.	142	Nut, oil pipes to crankcase.
31	Thackeray (spring) washer, rocker spindle.	72	Key, camshaft pinion.	107	Screw, spring.	143	Washer, oil pipe nut.
32	Cover, rocker inspection.	73	Key, camshaft pinion.	108	Lockplate, screw.	144	Rotor, alternator.
33	Cover, rocker inspection.	74	Camshaft, inlet and exhaust drive.	109	Pedal, gearchange.	145	Key, rotor to shaft.
34	Washer, cover joint.	75	Pinion, oil pump and distributor drive.	110	Bolt, gearchange pedal.	146	Oil seal, L.H. engine mainshaft.
35	Nut, cover securing.	76	Plunger, oil scavange.	111	Spindle and quadrant gear-change.	147	Washer, rotor fixing nut.
36	Washer, cover nut.			112	Plunger, gear selector.	148	Plug, cheescase filler.
37	Pushrod.					149	Washer, filler plug.
38	Cover, pushrod.						

Footchange Spindle and Quadrant Assembly. Remove the spring anchorage bolt and withdraw the assembly from the case.

Gear Indicator Cable. Disconnect the nipple at the camplate and unscrew adjuster to remove.

Camplate. Remove from the case.

Selector Forks and Spindle. Withdraw the spindle and remove the forks.

Kickstarter Shaft and Low Gear. Remove both of these units from the gearbox layshaft.

Mainshaft and Layshaft Gear Cluster. Take out of the casing as a complete assembly.

Cylinder Head. Unscrew the four sleeve nuts and lift off the head assembly.

Push Rods and Cover. Ease up the cylinder barrel enough to enable removal.

Camwheel and Camshaft Assembly. Withdraw from the timing chest. (The camwheel is marked for replacement purposes).

Tappets. Remove from the crankcase.

Timing Pinion. Slacken off the centre bolt one complete turn, then screw the extractor (Part No. Z94) into the pinion internal thread. Tighten the extractor bolt to withdraw pinion from the shaft taper. Remove extractor and unscrew pinion bolt to remove the pinion.

Oil Pump. Unscrew the two securing bolts and remove the assembly.

Distributor and Oil Pump Drive Shaft. If the driven gear shows no signs of wear and the shaft fit in the bush is good, the assembly should not be disturbed. To prevent the bush turning in the casing, replace the cover screw. If it is desirable to replace the parts, drive out the shaft complete with bush from inside of the casing.

Cylinder Barrel and Piston. Lift off the cylinder barrel. Remove one circlip from the piston gudgeon pin boss. Press out the gudgeon pin from the opposite end to remove piston.

Drive Side Inner Cover. Remove the two (later models; three) securing screws and tap the cover away from the main casing.

Flywheel Assembly. Turn the flywheels until the connecting rod is in the lowest position, and withdraw the assembly from the casing.

Mainshaft High Gear and Rear Drive Sprocket. Lock the sprocket to prevent it turning and unscrew the locknut. Drive the gear into the casing to release sprocket.

The Engine and Gearbox is now completely broken down into units, and it is proposed to deal with these units separately in such a manner that the fitter can dismantle, overhaul and re-assemble the major unit assemblies. By doing the work in this manner the assembly of engine and gearbox is simplified inasmuch as there is no sub-assembly to bother with whilst concentrating on the correct assembly of the unit.

PREPARATION

CYLINDER HEAD

Rockers and Spindles. Remove the rockers by knocking out the spindles from the threaded end. To prevent damage to the threads use a hide hammer or soft metal tool for this operation. After removing the spindles, the rockers and thrust washers can be taken out of the valve chambers. When inspecting for wear, check the ball ends and the adjuster pins. The spindle and rocker bore which is fully lubricated normally shows very little wear even after a considerable mileage.

Preparation of Cylinder Head

Valves and Springs. Compress the valve springs sufficiently with a compressor tool, when the split cotters can be eased away with a narrow screwdriver or similar tool. Release the tool and withdraw springs and valve. Repeat the operation to the other valve. Inspect the valve springs for signs of fatigue (Free length: Outer $1\frac{1}{8}$ " (4.13 cms.), Inner $1\frac{1}{16}$ " (4.0 cms.); if in doubt, a new set of springs should be obtained. Clean the valves and remove any burnt oil from the stems; if the valve faces are pitted they can be re-ground but excessive grinding by machine is not advisable, as the heat transference properties of the valve will be adversely affected; the stem of the valve should be inspected for wear and scuffing, and if either is pronounced it should be replaced.

Removing Carbon from Cylinder Head. Remove the carbon, with a round flat headed scraper from the head sphere and ports. Take particular care when cleaning around the valve seatings to avoid damaging the faces. Inspect the valve seats for pitting or pocketing, and valve guides for ovality. Remember, if the valve guides are changed the valve seatings must be re-cut. The same applies to a valve replacement or a valve which has had the seat face re-ground.

Replacing the Valve Guides. To replace the valve guide, use a shouldered drift and knock out from the inside of the combustion chamber. When fitting the new guide, assemble the circlip, lubricating the outer diameter and drift into the cylinder head from the rocker box end until the circlip just contacts the housing.

Grinding in the Valves. This should be done with a fine carborundum grinding-in paste. First smear a little paste around the valve face and insert the stem into the new valve guide. Attach the valve grinding tool to the stem tip and commence to grind the valve face to the valve seating, using a semi-rotary motion, occasionally turning the valve through 180° . Continue the process until a uniform seat results. Remove the valve and wash thoroughly in petrol or paraffin and examine the seating. A surer method is to apply a light even smear of "Engineers marking blue" to the face of the valve. Rotate the valve one complete revolution and then remove

it for inspection. A thin uniform line free from pit marks or other surface blemishes on valve face and valve seat indicates that the seating is satisfactory. After completion, the part must be thoroughly washed to remove all traces of the grinding-in compound.

Assembling the Cylinder Head. First ensure that all parts are perfectly clean, then oil the stem of the valve marked "IN" and insert into the inlet valve guide. Turn the head over ; holding the valve in position, slide the spring bottom cup over the guide, followed by the inner and outer valve springs and the top collar. Compress the springs with the spring compressor and assemble the two cotters to the valve stem. Release the compressor and finally give the valve stem tip a sharp rap with a hammer to ensure correct seating of the cotters. Repeat the operation for the exhaust side. The next operation is to replace the rockers. To do this grease the shim washer with the smaller hole and affix to the rocker end nearest the ball pin. Insert the rocker into the cylinder head and to replace the shim washers and spring washers to the opposite end, place the three together (spring washer in the middle) and grip the edge with a pair of round nose pliers. Now insert the washers between the rocker end and the valve chamber. Oil the spindle and push in from the sparking plug side. Carefully locate the rubber sealing washer on the spindle and tap the spindle through until the end is flush with the housing. Repeat the operation for the other rocker.

CYLINDER BARREL

Removing the Carbon. Remove all traces of carbon from the upper wall of the bore and then wash the cylinder barrel thoroughly. Check the amount of wear in the upper part of the bore by comparing it to the measurements in the lower. Anything over $+0.005$ " (0.127 mm.) will denote re-boring is necessary. A rough check can be made by checking the piston ring gap in various sections of the cylinder barrel bore. Normally the wear at the bottom of the bore is very light.

Piston. First remove the scraper and compression rings. Now clean away the carbon deposit from the piston crown by carefully scraping off. Any light deposit of burnt oil on the piston skirt should be removed by rubbing with a rag which has been dipped

Preparation of Crankcase and Covers

into a cleaning solvent (petrol-paraffin) Never, in any circumstances use emery cloth. To clean the ring grooves it is advantageous to use an old broken ring, by inserting the broken end into the groove and working it around the circumference. Clean out the drain holes in the scraper ring groove and then thoroughly wash the piston. If it is proposed to fit new rings, they must first be correctly gapped in the cylinder bore.

	Terrier.	Tiger Cub.
Minimum gap006 in. (0.15 mm.)	.008 in. (0.2 mm.)
Maximum gap008 in. (0.2 mm.)	.010 in. (0.24 mm.)

When making this check the ring must be fitted into the un-worn part of the cylinder bore, i.e. the lowest point.

Oil Pump. See Lubrication System, page 15.

CRANKCASE

In the flywheel compartment are the R.H. Mainshaft plain bearing, the distributor shaft bush, and the camshaft bush. The latter two are fairly easily replaced but we do not recommend the owner to disturb the plain bearing. This is a job which should be delegated to a Triumph Dealer who will have the necessary equipment to line ream it in position. Faulty fitting of this bush will result in lack of oil to the big end. In the gear compartment will be found the high gear journal bearing, the layshaft bush and the camplate index spring. To remove the journal bearing, simply press into the case, and always when making a replacement, re-assemble with a new felt oil seal. Do not omit the thin steel washer between seal and bearing. The index spring is removed by unscrewing the two securing screws, an operation which need not be undertaken if the plate shows no signs of wear. The layshaft bush is removed by first pressing out the sealing washer and then the bush. Replacement is made in the reverse manner but before replacing the sealing washer, check the layshaft fit in the bush.

Note.—The removal and replacement of all bearings is simplified by heating the crankcase to 100° C. (approximately boiling point).

CRANKCASE COVERS

Timing Side Inner. This cover houses three bushes and the clutch operating arm. The bushes may be replaced by pressing the old bushes out and the new bushes in. The clutch arm pivot anchorage is screwed into the crankcase; to remove turn arm anti-clockwise (R.H. thread). Check joint faces and remove any burrs.

Driving Side Outer. In the cover is housed the alternator stator. Care must be taken not to damage the winding. Clean and check the cover faces.

Driving Side Inner. The flywheel mainshaft journal bearing is housed in this cover. To remove it, warm the casing when the bearing can be pressed out complete with oil seal. The new bearing should be replaced in the reverse manner and a new oil seal must be employed.




Fig. 18
Flywheel Parting
and Assembly
Tool
Part No. Z101.

FLYWHEEL ASSEMBLY

The owner who is without workshop facilities is not advised to attempt the overhaul of the flywheel assembly; such work as this is far better entrusted to a Triumph Dealer who has a fully equipped workshop. For those owners who have the facilities and for others who are in outlandish places, a special tool, Part No. Z101 is required, together with a fitter's vice fitted with lead clamps.

DISMANTLING

Before attempting to split the assembly, carefully scribe two parallel lines at any point across the rims of the flywheels, using a fitter's square to ensure that the lines are at 90°. This procedure aids alignment during the re-assembly. On pages 45 and 47 are illustrated the four operations necessary to dismantle and assemble the flywheels. If a careful note is made of these, no difficulty should be encountered during the operation.

Driving Side Flywheel. Place the tool in position as in Fig. 19 and tighten the two $\frac{3}{8}$ " bolts into the threaded holes of the flywheel. Screw in the centre bolt and the driving side flywheel will be drawn off the crankpin. Remove the tool.

Big-End Bearing. Lift off the connecting rod. **N.B.**—Early Terrier models up to T.15 3905 had a roller big-end bearing.

Timing Side Flywheel. Position the tool as in Fig. 20 and this time the two $\frac{3}{8}$ " bolts are secured by nuts as the rear of the flywheel. Screw in the centre bolt and the crankpin will be pressed out.

EXAMINATION

The timing side main bearing controls the oil pressure at the big end, and if the main bearing journal is worn, the timing side flywheel must be replaced. The new timing side main bearing should be line reamed in position.

Unscrew the plug in the rim of the timing side flywheel and clean out the sludge trap. Replace the plug and peen the metal into the screw slot to lock the plug in position. Make sure that the other plug in the centre of the wheel is also secure.




Fig. 19.
Removing the
Driving Side Flywheel.




Fig. 20. Removing the Crankpin.

ASSEMBLING

Before commencing this work, clean all parts thoroughly with petrol or a degreasing agent. It is most essential that the oilways are clear and the flywheel crankpin bores free from oil. The Z101 tool used for dismantling can now be used for assembling.

Timing Side Flywheel. The crankpin must be pressed into the flywheel first and great care must be taken to ensure that the OIL HOLE in the CRANKPIN lines up with the OIL HOLE in the FLYWHEEL. Fit the tool as shown in Fig. 21, clamping the bolts to the outer face of the flywheel, with the two nuts. Tighten down the centre bolt and the crankpin will be pressed into the flywheel. Test the alignment of the crankpin to flywheel by blocking one hole in the crankpin and applying oil through a pressure oil gun into the opposite hole. If the alignment is correct the oil will flow through the crankpin and into the mainshaft.

Big-End Bearing. Lubricate the crankpin and the white metal big-end with clean engine oil. (Use a smear of grease to retain the rollers in position for the earlier roller big-end bearing). Wipe surplus oil from that portion of the crankpin which is inserted into the driving side flywheel.

Driving Side Flywheel. Assemble the flywheel to the crankpin and fit the tool as shown in Fig. 22 to the timing side. The two bolts are threaded through the timing side and screwed into the driving side. The bolts must be equally tightened down. Support the connecting rod in the up position and tighten down the centre bolt when the top assembly will be pressed into the driving side flywheel.




Fig. 21.
Replacing the Crankpin
into the Timing Side
Flywheel.




Fig. 22.
Fitting the Timing Side
Flywheel and Big End
Assembly to the Driving
Side Flywheel.

Preparation of Flywheel Assembly

Truing the Assembly. First check the flywheel alignment by placing a straight edge across the rims. This will indicate the highest wheel in that particular position. Mark the position with a piece of chalk and then place the assembly on the bench with the mark uppermost and towards the operator. Tilt the assembly to rest on the rear flywheel and then strike the marked flywheel rim a smart blow with a lead or hide hammer (see Fig. 23). Re-check the alignment with the straight edge and the fitter's square to see that the scribed lines are in alignment. If possible the assembly should be mounted in a jig on ball races and the flywheels and shafts tested for concentricity.




Fig. 23. Aligning the Flywheels.

RE-ASSEMBLY OF ENGINE AND GEARBOX UNIT

Before attempting to erect the engine first lay out all the parts in some order of assembly on a clean bench or if not available on a clean sheet of paper. Check that all unit assemblies are built up and that the various other parts including nuts, washers, split pins and gaskets etc., are all available. Also required is an oil gun (or failing this a can of clean engine oil and a paint brush). All the working parts should be liberally oiled before assembly.

Rear Drive Sprocket. Oil the gearbox high gear bearing and fit the mainshaft high gear. Assemble the rear drive chain sprocket to the gear and tighten up with the gear nut. Care should be taken to avoid damaging the felt oil seal when assembling the sprocket. Lock the sprocket to prevent it turning whilst tightening the nut. Lock the nut by centre punching in two places around the periphery of the thread.

Flywheel Assembly. Place the connecting rod in the lowest position and thread the assembly into the crankcase, entering the connecting rod through the cylinder aperture first.

Drive Side Inner Cover. Smear jointing cement round the crankcase joint face and assemble to crankcase. Replace and tighten the two hexagon-headed screws. (Later models one screw at top front also).

Crankcase Filter. Fit the short spring to the scavenge pipe then the filter and fit and tighten up the sump cap and washer. Well tighten to avoid loss. Pour a small quantity of oil into the crankcase (about an egg-cup full).

Piston Assembly. Position the piston over the connecting rod; enter the gudgeon pin into the small end from the opposite end to which the circlip is already fitted. Fit the remaining circlip and ensure correct positioning.

Cylinder Barrel. First put a rod through the gudgeon pin centre and turn the flywheel drive shaft until the rod rests on the crankcase cylinder base (see Fig. 15). Grease the base gasket and fit to the cylinder base flange. Place the cylinder barrel over the crankcase stud and gently lower until the cylinder spigot contacts the first ring. Ease each ring into the cylinder bore separately, and then correctly position the cylinder flange to crankcase.

Oil Pump. Fit paper gasket to the pump, ensuring that all holes are matched. Assemble to crankcase and eccentric shaft (see Fig. 3); well tighten the bolts.




Fig. 24. Valve Timing.

Timing Pinion. Turn the engine until the piston is at top dead centre and then set the distributor drive shaft so that the engaging slot is in line across the frame. Assemble the timing pinion to the flywheel mainshaft and engage the worm drive to the shaft driven gear and the pinion locating peg to the mainshaft. Check the length of the timing pinion bolt. This must not be longer than $1\frac{29}{32}$ " or the oil supply to the big end bearing may be cut off. Do not over-tighten the bolt or the bearing journal may be spread by the taper.

Tappets. Replace into the guides; check for freedom of action.

Camshaft and Wheel. Turn the flywheel assembly until the DOT on the timing pinion is uppermost and aligned with the tappet centres. Place the camshaft into the crankcase bush with the engaged key-way in the downward position. Now mesh the gears together so that the DOTS on camshaft wheel and pinion coincide. (See Fig. 24).

Gear Cluster. Fit the layshaft and mainshaft gears together as shown in Fig. 25 and place into the gearbox casing as a complete assembly.

Selector Forks. Assemble the forks back to back onto the selector rod. Fit the assembly into the casing engaging the forks to the gear selector grooves, then locate the rod into its housing. Do not oil the rod end or housing as a hydraulic lock may occur causing difficulty in final assembly.

Camplate. Put the camplate into the casing with the bush pointing towards the unit front and the indicator rod in the guide. Position the grooves over the selector rollers.

Plunger Guide Assembly. Fit the footchange pedal return spring. To do this hold the plunger spindle in the left hand and the eye end of the spring in the right hand. Push the open end of the spring over the groove in the back half of the spindle. Then holding the spring in this position, turn the eye completely over (180°) at the same time forcing the spring forward to engage the upper peg. Fit the assembly to the gearbox engaging the plungers into the camplate. Replace the shouldered bolt through the spring eye and screw and tighten into casing.




Fig. 25.
The Mainshaft and Layshaft
Gear Clusters.

Kickstarter Shaft. Place the pen steel washer in the layshaft low gear, and then place the shaft in position engaging the pawl into the ratchet. Position as shown in Fig. 26.

Timing Side Inner Cover. Smear jointing compound on the inner joint face. Remove the screw from the distributor oil pump drive shaft which has held the shaft bush in position and fit the inner cover to the unit casing. Replace the bush locating screw and the other three remaining screws.




Fig. 26.

View of the Gears and Selector Mechanism in position.

Camplate Spindle. If the camplate bush will not align with the inner cover boss, fit the footchange pedal and depress it or raise it as necessary to align the holes. Enter the spindle so that the split pin hole aligns with the bush hole and fit a $\frac{1}{8}$ " (3 mm.) split pin.

Camplate Spindle Cover. Fit the cover and cork washer to the inner cover and tighten the two screws.

Kickstarter Spring and Stop Plate. Fit the spring in the manner shown in Fig. 27. Now engage the lockplate tab into the spring loop. Turn plate against the spring tension (anti-clockwise) and fit the plate to the spindle as per Fig. 27.




Fig. 27.

Kickstart Spring in the fully wound position.

Clutch Cable. Thread the cable wire through the inner cover. Connect the nipple to the clutch arm and then coil the cable to prevent the nipple disengaging.

Timing Side Outer Cover. Smear the paper joint washer with grease, and place it in position on the outer cover. Fit the outer cover and tighten the screws securely, as the screws also retain the inner cover.

Footchange and Kickstarter Pedals. Replace to the shafts.

Distributor. Replace this unit and time the ignition. (See page 56).

Push Rods and Cover Tube. On the bottom of the cover tube there will be noted a small slot in the centre tube which mates with the peg in the crankcase when fitted. Fit the rubber washer to the lower end of the tube and the cream silicone rubber washer to the upper part. Sufficiently raise the cylinder barrel to enable the fitting of the cover tube and then lower it. Position the push rods to the tappets, INNER push rod to the EXHAUST ROCKER and OUTER push rod to INLET ROCKER. (See Fig. 16).

Cylinder Head. Grease the copper gasket and fit to the cylinder barrel top flange. Assemble the head *complete with exhaust pipe clip*, carefully locating the push rods to their respective rockers. (See Fig. 16). Finally tighten down with the four sleeve nuts.

Valve Clearance. Re-set the clearance to 0.010" (0.25 mm.). See page 21 for further information.

Clutch, Engine Sprocket and Rotor. See Clutch, page 60.

Drive Side Outer Cover. Fit as described above (Timing Side Outer Cover) making sure that there is no slack in the alternator lead and that the screws are tight.

Drain, Level and Filler Plugs. Replace these plugs and DO NOT forget to replenish the gearbox and primary chaincase with oil after fitting the unit to the frame.

REFITTING ENGINE AND GEARBOX UNIT TO FRAME
Assemble in the reverse manner to that described on page 34.

IGNITION TIMING

FITTING THE DISTRIBUTOR

Before the distributor can be replaced the piston must be correctly positioned in relation to the opening and closing of the valves. To do this, rotate the engine until the inlet valve closes (if the cylinder head is not fitted, check the movement of the inlet tappet), and the piston ascends to the top of its stroke. The piston position is now at T.D.C. (top dead centre) on compression stroke. The slot in the distributor drive shaft will be in line across the frame.

There is a rubber "O" ring seal fitted to the top of the distributor shank and it should be replaced by a new one if broken or damaged. Remove the cover from the distributor head and rotate the shaft anti-clockwise until the peak of the cam is just on the contact breaker heel. Assemble the distributor to the crankcase and driving shaft with the contact breaker points in the 7 o'clock position (operator facing the timing side of the engine). Lock the distributor clamp to crankcase and tighten up the clamp bolt. The engine is now ready for timing.

TIMING DRILL

Marking the Timing Stick. To find the true T.D.C. when the cylinder head is fitted, it will be necessary to use a timing stick through the sparking plug hole. First engage TOP gear and then place the timing stick through the plug hole and allow it to rest on the crown of the piston. Now rock the rear wheel to and fro until T.D.C. can be accurately felt.

Terrier only. Mark the lowest part of the timing stick which is visible to the eye level and then remove the stick and make a further mark $\frac{1}{8}$ " (0.4 mm.) above the first mark.

Positioning the Piston. The Tiger Cub is timed at T.D.C. but the Terrier is timed $\frac{1}{8}$ " B.T.D.C. and it is necessary to carry out the procedure in the following paragraph.

Rotate the rear wheel backwards until the piston has fallen about a $\frac{1}{4}$ " (6.5 mm.) then reverse the rotation (as for forward travel) and slowly bring the piston up to the $\frac{1}{8}$ " (0.4 mm.) mark. This procedure eliminates any error due to backlash in the timing gears. If the ignition timing is to be carried out when the cylinder head is not fitted a depth gauge should be employed in place of the timing stick.

Positioning the Distributor. Slacken off the clamp bolt and rotate the distributor housing slightly (contact breaker points at 7 o'clock) until the points just open. In order to ascertain accurately the exact point of opening, slip a .0015" (0.04 mm.) feeler gauge or a piece of tissue paper between the points. Rotate the distributor housing and the gauge will be released as soon as the points start to open. Tighten up the clamp bolt.

Checking the Timing. Rotate the engine backwards and insert the feeler gauge between the contact points, then reverse the rotation and turn until the feeler gauge is just released from the points. Place the timing stick into the sparking plug hole or depth gauge on the piston, as the case may be, and check the piston position. If correct, re-check the clamp bolt for tightness and replace the sparking plug and connect up the lead.

For the owner who wishes to use a more accurate means of detecting the opening of the contact points, a lamp and battery should be employed. The lamp and battery are joined together in series with the two contact points which act as a switch in the circuit. To operate, join one of the two leads from the battery and bulb to the terminal on the distributor, and the other lead to the frame earth. The bulb remains alight until the points open.

VALVE TIMING

The assembly of the timing gears is fully explained on page 51, "Re-assembly of Engine and Gearbox". On page 50, Fig. 24 clearly illustrates the meshing of the marked gears. For normal conditions the set timing will give the best all-round performance.

CLUTCH

(See also Page 110)

The clutch is the three plate cork type incorporating a transmission shock absorber. The pressure on the plates is made by three equally disposed springs which can be varied by screwing in or out the three slotted nuts which secure them. The clutch is designed to operate in oil and it is therefore essential that the oil level in the primary chaincase is maintained, otherwise the cork inserts may burn and disintegrate when the clutch is slipped or when a heavy load is transmitted. Always use the recommended oil (20 S.A.E. viscosity) as if a heavy grade of oil is used, the clutch will not separate when disengaged, which will cause noisy engagement when selecting a gear. Even with the thinner grades of oil in use, the kickstarter should always be operated a few times with the clutch extracted before starting the engine. This procedure ensures that the plates will operate freely when a gear selection is made.

REPLACEMENT OF THE CORK INSERTS

We do not recommend a replacement of the cork inserts by the owner. This is a job which calls for a certain amount of precision and special equipment to reduce the new inserts to the correct thickness and an even overall surface after fitting to the sprocket and plates. The better method is to remove the sprocket and plates and exchange them under a service replacement scheme at the nearest Triumph Dealer. The following paragraphs deal with the removal and replacement of the clutch plates and sprocket. If the clutch is to be completely broken down, the shock absorber information will be found in subsequent paragraphs. Here again it is far better to obtain a service replacement unit.

REMOVING THE CLUTCH SPROCKET AND PLATES

Place the machine on the central stand and put an oil drip tray under the primary chaincase, then proceed as follows.

Footbrake Pedal. Remove the split pin from the brake rod and withdraw the rod. The pedal will now fall clear of the chaincase.

Footrest (Left Hand). Unscrew the securing nut and remove the footrest.

Outer Primary Chaincase. Remove the chaincase screws. This operation requires a special "Phillips screwdriver". When the screws have all been removed, tap the cover around the joint face with a mallet or the handle of a hammer to break the joint.

Clutch Slotted Nuts. Unscrew these by using the special key provided in the toolkit. On the underside of the head of the screw is a small "pip" to prevent the nut from unscrewing. To facilitate removal, insert a knife blade under the head of the nut, in order to hold the spring away from the "pip" while the nut is turned.

Pressure Spring. Withdraw from the cups.

Pressure Plate. Remove complete with the cups.

Clutch Plates. Withdraw the corked and plain plates from the housing.

Sprocket. As the primary chain is of the endless type, the engine sprocket, clutch sprocket and chain must be withdrawn as an assembly. To do this, remove the alternator rotor locknut, and withdraw the rotor. The sprockets and chain can now be removed.

This completes the dismantling for this particular operation, the shock absorber assembly being left intact with the back plate.

INSPECTION OF PARTS

Clutch Springs. The free length of the spring should be $1\frac{21}{32}$ " (42 mm.); if a spring measures less than $1\frac{17}{32}$ " (39 mm.), a new one should be employed.

Cork Plate. Wash in paraffin and examine the corks for wear and general condition. The cork inserts should protrude $\frac{3}{8}$ " (1.2 mm.) each side of the plate. Inspect the tabs for wear which will be evidenced by steps.

Plain Plate. This should move freely on the clutch centre; any signs of sticking should be investigated and the offending high spots removed. To ensure a good clutch action, the plates must be perfectly flat and there must be no evidence of scoring, as this will cause rapid wear of the cork inserts.

Sprocket. Here, three inspections should be made. The condition of the cork inserts which should protrude $\frac{1}{4}$ " (0.4 mm.) recess side, and $\frac{1}{8}$ " (3.2 mm.) outer side (measurement from sprocket edge) of the sprocket, the bearing ring which should be free from pitting and the sprocket teeth for "hooking". The first two conditions can be rectified by fitting new parts. Failure of the sprocket teeth however, will mean a complete new assembly.

ASSEMBLING THE SPROCKET AND PLATES

Before commencing to assemble the parts, the clutch sprocket and corked plates must be thoroughly soaked in oil (SAE-20), and the clutch operating rod correctly positioned.

Sprocket.

Fit the chain to the clutch and engine sprocket ensuring that the recessed side of the clutch sprocket will be towards the back plate when fitted. Fit the assembly to the clutch centre and engine sprocket. Replace the A.C. rotor and fit and tighten the nut.

Plain Plates. Fit to the clutch centre and check for freedom of movement.

Cork Plate. Engage the locating tabs into the sprocket slots and ensure that the part assembles freely. Then assemble the remaining plain plate and cork plate.

Pressure Plate. Fit the plate complete with cups to the clutch.




Fig. 28. CLUTCH COMPONENTS

Index No.	Description.	Index No.	Description.	Index No.	Description.
1	Sprocket.	8	Cup, spring.	15	Rubber, drive.
2	Cork insert, sprocket.	9	Nut, pressure spring.	16	Rubber, rebound.
3	Plate, driven (plain).	10	Centre.	17	Ring, sprocket bearing.
4	Plate, driving.	11	Cup, centre driving.	18	Bail, sprocket bearing.
5	Cork insert, driving plate.	12	Plate, backing.	19	Locknut, adjuster.
6	Plate, pressure.	13	Pin, backing plate.	20	Adjuster, pressure plate.
7	Spring, pressure.	14	Spider.		

Clutch

Pressure Springs. Insert the springs into the cups and over the studs.

Slotted Nuts. Start each nut on the three studs and screw them down until the stud end is almost flush with outer face of the nut.

Final Adjustment. Test the operation of the clutch by lifting the clutch lever; if the movement is harsh, this denotes a faulty cable which probably requires lubricating (see page 89). There should be about $\frac{1}{16}$ " (1.6 mm.) free movement at the handlebar lever to allow for initial wear.

Provision for adjustment is made at the handlebar end of the cable. Now lift the clutch lever and depress the kickstarter, at the same time observing the clutch pressure plate. The plate must spin true without any sign of "wobble". If the plate does not spin true, rectify by screwing in the screw adjacent to the part of the plate which is the furthest away from the sprocket. Spin the clutch again and re-check. It is most important that this adjustment is made correctly, otherwise the rider will experience trouble when making a gear selection, due to a "dragging" clutch.

Outer Primary Chaincase. Grease a new paper joint washer and place it on the outer cover. Make sure there is no slack in the alternator lead and tighten the screws. N.B.—These screws also secure the inner cover and must be kept tight.

Footbrake Pedal and Footrest. Re-position the pedal and replace the split-pin in the rod. Fit the footrest to the rod and replace and tighten the nut.

CLUTCH SHAFT SHOCK ABSORBER

(See also Page III)

As previously stated, the private owner is advised to obtain a service replacement unit rather than endeavour to overhaul the unit in use. To those who wish to carry out the overhaul it is essential first to obtain the new rubbers, studs, extractor, and, if possible a discarded gearbox mainshaft. Proceed as follows:—

DISMANTLING

Clutch to Mainshaft Nut. First remove the clutch operating rod and then bend back the tab on the lock washer and unscrew the nut. The nut can either be shocked loose by applying a hammer blow to the box spanner tommy bar, or by engaging low gear and applying the rear brake whilst turning the spanner.

Shock Absorber Unit and Backplate. This is removed as a complete unit by screwing in the extractor Part No. Z95, and tightening the extractor bolt. The whole assembly will be drawn off the gearbox mainshaft taper.

Splitting the Assembly. The shouldered studs which hold the assembly together are locked to the backplate by peening over the end thread. The studs can be removed by screwing on two $\frac{1}{4}$ " \times 26 B.S.F. nuts as locknuts and then turning on the lower nut when the studs will be screwed out of the back plate.

Shock Absorber Unit. Press the spider out of the centre, when the rubber inserts and cups can be removed.

ASSEMBLY

Before assembling the unit, follow carefully the illustration on page 64 (Fig. 29) when reading the following instructions:

Cups. Insert the cups (large diameter) into the clutch centre.

Spider. Put the spider into the clutch centre with threaded end downwards.

Clutch Shaft Shock Absorber

Rubbers. Before attempting to replace these, examine carefully Fig. 29 below which shows the rubbers in position when looking from the back of the clutch, this being the view the operator will have when replacing them. Insert the drive (large) rubber first and then assemble the spider unit to a mainshaft (this should be held horizontally in a vice). Fit a suitable "C" spanner to the clutch centre using the slots as a medium for turning. Turn the spanner to apply pressure against the drive rubbers, when the rebound rubbers can be easily inserted.

Shock Absorber Unit to Backplate. Place the unit on the backplate and assemble the studs through the cups; screw them into the backplate, using two locknuts to tighten (as in dismantling), if a stud driver is not available. Lock the studs to the back by peening over. Replace the lockwasher and shaft nut and tighten. Position the clutch operating rod.

To assemble the remainder of the clutch, turn to page 60.




Fig. 29. SHOCK ABSORBER UNIT

This shows the rubbers in position when viewed from the back of the Clutch.

TELESCOPIC FORKS

MAINTENANCE

The fork will require only a periodical greasing (4,000 miles). To carry out this maintenance, remove the headlamp assembly when access can be gained to the two grease nipples situated in the stanchion tubes. Approximately half a grease gun full of grease should be pumped into each fork leg. During this servicing, check the external fittings for tightness.

It is estimated that, under normal conditions the fork should be dismantled and new bushes fitted at 20,000 miles.

ADJUSTING STEERING HEAD RACES

Lower the central stand and to ensure that the front wheel does not contact the ground, place a box of suitable height under the crankcase. Test the amount of play in the steering races by gripping the fork members and rocking them in a fore and aft direction. Remove the headlamp and fixing ring and nacelle unit instrument assembly when access can be gained to the adjusting nut.

Pinch Bolt. Slacken off the nut.

Adjusting Nut. Tighten down this nut as far as it will go, but do not apply more than two finger pressure on the spanner.

Testing. The fork should move to the full lock position in both directions under its own weight. If the movement is sluggish, slacken off the adjusting nut slightly and test again. When the final adjustment has been made, tighten up the pinch bolt, remove the box from underneath the crankcase and re-fit nacelle unit and headlamp assembly. Finally check the steering when riding the machine on the road.

CHANGING THE FORK SPRINGS

It is not necessary completely to dismantle the fork assembly to carry out this operation. Before commencing the work the operator should have available two new grease retainer felts which fit in the lower member sleeve nut and, of course, the two new springs.




Fig. 30.
TELESCOPIC FRONT FORK.
 For Index see page 67.

DISMANTLING

Headlamp and Nacelle Top Unit. Remove in the manner explained on page 99.

Front Wheel. Remove (See page 77).

Lower Member Sleeve Nuts. Unscrew until completely released from member.

Spring Stud Top Nuts. These are located in the centres of the large nuts which secure the top lug to the stanchions. Unscrew and remove.

INDEX TO FIG. 30

<i>Index No.</i>	<i>Description.</i>	<i>Index No.</i>	<i>Description.</i>
1	Lug, fork stem and middle	21	Boit, cover cap.
2	Bolt, middle lug pinch.	22	Washer, cap bolt.
3	Nut, pinch bolt.	23	Cover, bottom T.S.
4	Washer, pinch bolt.	24	Bush, bottom cover top.
5	Lug, top.	25	Sleeve nut, bottom cover.
6	Bolt, top lug pinch.	26	Washer, sleeve nut steel.
7	Nut, pinch bolt.	27	Washer, sleeve nut felt.
8	Washer, pinch bolt.	28	Nacelle, bottom unit.
9	Sleeve nut, fork stem.	29	Nacelle, top unit.
10	Stanchion.	30	Flash, R.H. chrome.
11	Grease nipple.	31	Flash, L.H. chrome.
12	Bush, stanchion bottom.	32	Cone, steering rate top and bottom.
13	Nut, stanchion to top lug.	33	Cover, dust.
13a	Washer, top lug nut.	34	Clip, to mudguard bridge.
14	Spring.	35	Support, top lug to handlebar.
15	Stud, fork spring top.	36	"U" bolt, handlebar to top lug.
16	Stop, fork spring bottom rod.	37	Nut, handlebar "U" bolt.
17	Rod, fork spring bottom.	38	Washer, buffer.
18	Nut, fork spring top stud.	39	Buffer, stanchion.
19	Cover, bottom D.S.		
20	Cap, bottom cover.		

Lower Members. These can now be withdrawn complete with springs after removal of the grease nipples from the stanchions.

Springs. Secure the wheel lug of the lower member in the vice; grip and turn the spring anti-clockwise to release the lower fixing stud from the member. Withdraw spring assemblies.

Rubber Buffer. These are located in the bottom of the member tube. To remove, tap the tube open, end downwards, on a piece of wood.

PREPARATION

Remove all traces of old grease from dismantled parts and examine the sleeve nut grease seal. If the seal has not been disturbed, replacement will not be necessary. If on the other hand it shows signs of uneven seating, replace with the new felt. Inspect the rubber buffers and replace if unduly compressed.

ASSEMBLY

Rubber Buffers. Fit to the lower spring studs (long).

Springs. Grease the springs and enter into the lower member (long stud first). Screw the studs into the wheel lugs by turning the springs (clockwise).

Lower Member Assembly. Grease the stanchions, lower and upper bearings, then enter the spring into the stanchion and slide the lower member over the stanchion. Enter the top bush into the member and press into place.

Sleeve Nut. Tighten to the lower member.

Top Stud Nut. Force the lower member up until the top stud enters the larger nut, then replace the stud nut and tighten.

Wheel. Replace (see page 81).

Headlamp and Nacelle Unit. Replace (See pages 98 and 99).

REMOVING FORKS FROM THE FRAME

First remove the front wheel, mudguard, headlamp assembly and nacelle top unit as described on pages 77 and 99, then proceed as follows.

Handlebar. Detach control cables from levers and twist-grip. Remove the dipper switch. Unscrew the four nuts off the "U" bolts, when the horn will be released and the "U" bolts can be removed. Remove the handlebar and distance pieces.

Top Lug Pinch Bolt. Slacken off the nut only.

Headrace Adjuster Nut. Unscrew off the fork stem.

Spring Stud Nuts. These are located in the large top lug to stanchion nuts; remove by unscrewing in the normal manner.

Top Lug to Stanchion Nuts. Slacken off three or four turns and then break the taper joint between stanchion and lug by striking the head of the nuts smartly with a hide or lead hammer.

Top Lug. Supporting the lower lug, remove the two large nuts and tap the lug off the fork stem.

Fork. Lower the remainder of the assembly taking care not to lose the ball bearings in the lower race.

Top Race. Remove the dust cover and take away the top cone when the ball bearings can be removed from the headrace cup.

DISMANTLING THE FORK

Middle Lug Pinch Bolt. Slacken the nuts.

Lower Member Assemblies. Remove the grease nipples and then withdraw the stanchions through the middle lug.

Lower Nacelle. Remove the two pinch bolts when the middle lug can be detached from the nacelle cover.

Sleeve Nuts. Unscrew the nut from the lower member and remove.

Stanchions. Place the wheel lug of the lower member in the vice and sharply pull the stanchion out of the member. By doing this the upper bearing will be extracted with the stanchion, the lower bearing being captive.

Springs. Whilst the lower member is in the vice the spring can be removed by gripping the exposed coils and turning the spring anti-clockwise (R.H. thread).

Rubber Buffers. Remove from lower members.

INSPECTION AND PREPARATION

First thoroughly degrease all parts and lay out for inspection. If the mileage covered is in excess of 20,000 miles it is recommended that all bushes and seals are changed.

Stanchion. First ensure that the stanchion is true by laying a straight edge along it, or by rolling it on a surface plate or piece of plate glass to ascertain if there is any distortion. The maximum amount should not exceed $\frac{5}{16}$ " (8 mm.) if the stanchion is to be put into further service after straightening. The owner is not advised to undertake the servicing of a fork in this condition; it should be returned to a Triumph Dealer for an exchange service replacement.

Stanchion Bottom Bearing. To remove, drill out the holes in the bearing with a $\frac{5}{32}$ " (4 mm.) drill when the bearing can be withdrawn from the stanchion. To fit the new bearing, a metal bar of suitable diameter to fit the inside of the stanchion and a wide shallow pointed centre punch is needed. Secure the bar in the vice and then fit the new bearing to the stanchion, aligning the holes in the bearing to those in the stanchion. Place the bearing end of the stanchion over the metal bar and fit the centre punch point into the bearing oil holes. Gently tap the punch with a hammer to lock the bearing to the stanchion. Repeat the operation with the other holes.

Sleeve Nut Felt Seal. Remove the thin metal washer and take out the seal. Apply a heavy grease to the new seal and replace in the sleeve nut followed by the metal washer.

Rubber Buffers. If damaged or unduly compressed these should be replaced.

Lower Member. Examine for indentation and scrap if defective.

Springs. If the coils are not unduly compressed the springs are fit for further service. The free length of the spring should be within $\frac{1}{2}$ " (12.7 mm.) of the total length which is $17\frac{1}{4}$ " (43.9 cms.)

Middle Lug. If the motorcycle has been involved in an accident the lug will require expert attention. No attempt should be made to carry out this work without jigs.

Top Lug. The same applies as described in the paragraph above.

Nacelle. Examine for indentation and distortion and rectify.

Top Bearing. Slide the bearing onto the stanchion and estimate the wear by moving the bearing from side to side. Any appreciable movement will denote wear and the bearing must be changed.

Steering Races. Remove all traces of grease from the cups, cones and balls and examine for indentations, pitting and wear. If there is any sign of these defects, the parts should be changed to ensure good steering.

ASSEMBLING THE FORK

Before commencing to assemble the fork, grease all working parts liberally.

Rubber Buffers. Thread over the spring long studs.

Springs. Place the long stud end of the spring into the lower member, screw the stud into the wheel lug and tighten.

Telescopic Forks

Stanchion. Thread the stanchion (bearing end) over the spring and enter into the lower member. Test the stanchion movement in the member, this should be quite free.

Top Bearing. Fit the bearing over the stanchion and into the lower member.

Sleeve Nut. The nut complete with seal is now fitted over the stanchion and screwed onto the lower member.

Middle and Top Lugs. Fill the frame top and bottom steering races with grease and assemble 15 balls $\frac{1}{4}$ " (6.35 mm.) dia. into each cup. Enter the middle lug stem into the bottom race and holding it in position, slide the top cone over the stem, followed by the dust cover, top lug and finally screw on the adjusting sleeve nut finger tight. Fit the pinch bolt and nut but do not tighten.

Lower Nacelle. Assemble to the middle lug and hold in position by fitting the pinch bolts and lightly tightening up the nuts. The two screws which secure the nacelle to the top lug should be temporarily fitted at this stage.

Lower Member Assemblies. Enter the stanchion through the middle lug and into the taper in the top lug. Secure the stanchion to the top lug with the large nut and fork spring stud with the small nut. Well tighten the large nut with a ring spanner and then the small centre nut. Do not tighten up the middle lug to stanchion bolts at this stage.

Mudguard. Replace to the forks and secure all fastenings.

Front Wheel. Fit the wheel to the forks and ensure that the spindle ends protrude equally through the fork spindle lugs (See page 81).

Handlebars. Fit the two distance pieces to the top lug, then the handlebar and secure with the two "U" bolts. Turn the handlebar to the desired position and tighten up the four "U" bolt nuts. **DO NOT FORGET TO REPLACE THE HORN AT THIS STAGE.**

Pinch Bolts (Middle Lug to Stanchions). The pinch bolts may now be fully tightened.

Pinch Bolts (Top Lug). See page 65, "Adjusting the steering head races."

Nacelle Top Unit. Thread the control cables through the respective handlebar rubber grommets and position the grommets to the lower nacelle. Replace the top unit connecting the electrical and speedometer cables as described on page 99.

Control Cables. Replace to the levers and gear indicator control.

Headlamp. Replace the headlamp after connecting the electrical cables to the bulb connections.

REAR SUSPENSION

Provision for greasing the suspension is made by pressure grease gun through the fork end nipples. The assembly should be greased every 1,000 miles. The construction of the suspension is simple as will be seen in Fig. 31 and wear on the moving parts is negligible. If after a period of time the springs settle down or the gaiters require renewing, the parts can be replaced at small cost. This job can be done without special tools but the task of compressing the springs sufficiently is a fairly difficult operation. In view of this, a compressor tool, Part No. Z100, has been designed and will be in the hands of most Triumph Dealers. It will be more economical, therefore, to entrust this work to your dealer who will be able to carry it out efficiently and quickly. For those who wish to carry out their own maintenance, proceed as follows:—

DISMANTLING

Rear Wheel. See page 82 for removal.

Locknut. Remove the locknut from the plunger guide rod.

Clamp Bolt. Unscrew the nut and tap out the bolt.

Plunger Guide Rod. Place a good screwdriver into the slotted head of the rod and turn in an anti-clockwise (right hand thread) direction. Continue to turn until the rod is free in the lower lug and then withdraw the rod.

Fork End and Springs Assembly. Great care will have to be exercised when removing this assembly as the springs are under considerable tension. To prevent injury, place an old sack or similar material over the frame end and then ease the assembly away with a screwdriver. The sacking will prevent the parts flying in all directions immediately they are free. Repeat the operation to the opposite assembly.

INSPECTION AND PREPARATION


First wash all parts in a cleaning solvent.

Plunger Guide Rods. Inspect for pitting, wear and rusting. If the pitting is light, ease down with a fine emery cloth. A worn rod will have to be replaced, but in the case of rust (due to lack of lubricant) rubbing down with fine emery cloth is permitted.

INDEX TO FIG. 31

<i>Index No.</i>	<i>Description.</i>
1	Fork end, R.H. Fork end, L.H.
2	Nipple, grease.
3	Pin, fork end brake anchorage.
4	Backing washer, plunger lug.
5	Gaiter, plunger rubber.
6	Spring, suspension main.
7	Spring, suspension rebound.
8	Cover, suspension spring (lower).
9	Cover, suspension spring (upper).
10	Rod, plunger guide.
11	Locknut, plunger guide rod.

Fig. 31.
REAR SUSPENSION.
For Index see page 74.



Spring Covers. These must be free from indentations.

Fork Ends. Fit to the plunger guide rods and check wear. Apply a grease gun to the grease nipples to ensure the free entry of grease when the gun is operated.

Spring. The free length of the springs when new is $4\frac{7}{8}$ " (12.4 cms.) (main), and $2\frac{3}{4}$ " (7 cms.) (rebound).

ASSEMBLY

Before commencing to assemble the parts, carefully view Fig. 31. This illustration shows the left hand assembly (Brake side), which has the anchorage pin fitted to the fork end. The right hand fork end has no anchorage pin fitted.

Fork End and Spring Assembly. Grease all the parts and assemble items 1 to 9 (Fig. 31) and if available place in the compressor tool and compress sufficiently to enter the frame rear lug. Without this tool, a rod should be inserted into the lower hole of the lug and the assembly threaded over it. Pressure will now have to be exerted on the top cover of the assembly in order to position it between the lugs. When in position, do not forget to replace the washer between the top cover and lug.

Plunger Guide Rod. Remove the rod used to assist during assembly and insert the guide rod through the top lug and screw into the bottom lug.

Clamp Bolt. Fit the bolt into the top split lug, replace the nut and tighten to clamp the guide rod.

Locknut. Fit and tighten the locknut on the plunger guide rod.

Repeat the operation to the opposite assembly and then replace the wheel (see page 85).

WHEELS

Maintenance such as greasing the wheel bearings is unnecessary until the machine has covered at least 10,000 miles. Cases may arise where conditions are extremely severe when an inspection of the internal parts is advisable prior to this mileage.

No grease nipples are fitted to the hubs, as the bearings etc., are, sufficiently well greased during assembly to cover the above mentioned period.

The bearings are of the heavy duty ball journal type and cannot be adjusted. Excessive play at the wheel rim will denote bearing wear, a condition which can only be remedied by replacing the worn parts.

The design of the wheel is extremely simple and will not in any way prove difficult to the owner who wishes to carry out his own maintenance if he follows these instructions.

FRONT WHEEL

REMOVAL

Brake Cable. Disconnect at cam lever and detach from anchor clip.

Anchor Plate Nut. Remove.

Spindle to Fork Leg caps. Remove the four bolts securing the caps to the fork legs when the wheel will be released. Raise the front of the machine and withdraw the wheel assembly.

DISMANTLING

If a vice is available, soft clamps should be fitted to the vice jaws to prevent damage to the wheel spindle when the latter is clamped in position.

Wheel. Place in the vice, holding by the wheel spindle opposite to the brake drum end.




Fig. 32. FRONT WHEEL. For Index see page 79.

Anchor Plate. Unscrew the central nut and then easing the brake lever slightly towards the "on" position, withdraw the anchor plate assembly away from the brake drum.

Brake Shoes. Release the "pull-off" springs when the shoes can be removed from the anchor plate. Avoid grease contact with the linings if they are to be used for further service.

Bearing Retaining Ring. This ring has a LEFT HAND thread and to remove place a peg spanner into the diametrically opposed holes and unscrew from the hub.

Bearing (Brake Drum Side). To remove, first take the wheel out of the vice and bump the spindle end (the end opposite the brake drum) on a piece of hard wood. This will push the bearing out of the hub and also release the spindle.

Bearing (Opposite Brake Drum). Turn the wheel over so that the brake drum rests on the bench. Remove the circlip securing the bearing dust cover. Now hold the wheel in a vertical position and place a drift of either metal tubing or wood through the hub until it rests against the bearing outer race. Tap the opposite end with a hammer and the bearing and dust cover will be driven out of the hub.

The wheel is now ready for examination (see Page 81) and rectification.

INDEX TO FIG. 32

Index No.	Description.	Index No.	Description.
1	Rim, front wheel.	12	Ring, front wheel R.H. locking.
2	Spoke, right hand (short).	13	Plate, front brake anchor.
3	Spoke, left hand (long).	14	Cam, front brake.
4	Nipple, spoke.	15	Lever, front brake.
5	Hub and brake drum assembly.	16	Nut, front brake lever.
6	Spindle, front wheel.	17	Shoe, front brake c/w lining.
7	Nut, front wheel spindle.	18	Lining, front brake.
8	Bearing, front wheel L.H.	19	Rivets, front brake lining.
9	Dustcap, front wheel L.H.	20	Spring, front brake shoe.
10	Circlip, front wheel L.H.	21	Nut, front brake anchor.
11	Bearing, front wheel R.H.		

ASSEMBLY OF WHEEL

Bearing (Brake Drum Side). Grease the larger bearing and place into the hub. Drive the bearing in until it contacts the machined ledge.

Bearing Retaining Ring. Screw into the hub, remembering that the thread is left hand. Tighten with a peg spanner.

Spindle. Insert the spindle from the opposite end, the shoulder contacting the bearing now in position. Fill into the hub sufficient grease (dessert spoonful).

Bearing (Opposite Brake Drum). Over the spindle place the smaller bearing (well pack with grease before fitting) and press into position.

Dust Cover. Place the open end downmost over the spindle and press or drive into the hub until the circlip groove is visible.

Circlip. Enter into the hub groove and ensure that it is correctly positioned.

Anchor Plate. Grease the brake shoes operating cam spindle and place lever correct to the relative operating position, i.e. cam flats in line with the pivot point and lever facing rearwards and downwards.

Brake Shoes. First ensure that the hands are completely free from grease before handling the brake shoes, otherwise their efficiency will be impaired in use. Pair the shoes together and fit the springs; take a shoe in each hand, holding them sufficiently apart to keep the springs in position. Now turn the shoes towards the body until they can be placed in position over the cam and pivot point; then press them down and both will snap into position.

Anchor Plate Assembly. Slide the distance piece over the spindle and then the anchor plate assembly. Finally tighten down with the locking nut.

The wheel is now ready for assembly to the forks.

ASSEMBLY OF WHEEL TO FORKS

First raise the front of the machine and then place the wheel between the fork legs.

Wheel. Position the wheel spindle to the fork bottom lugs and engage the anchor plate stud into the fork leg clip. Loosely assemble the nut and washer to this stud.

Spindle Caps. Screw these caps into position, but before finally tightening make sure that the spindle just protrudes at each end and then tighten up the bolts.

Anchor Plate Nut. Well tighten up this nut.

Brake Cable. Engage the cable at the adjuster point and connect up the clevis to the lever. Suitably adjust the brake cable.

INSPECTION OF FRONT AND REAR WHEEL

Wash all the parts in a cleaning solvent then carry out the following inspection.

Bearings. Check for wear by holding the centre race and moving the outer race across its axis; spin the outer race to check for roughness. Finally hold the bearing to the light and inspect both upper and lower track and balls for pitting or indentation. If found to be faulty the bearings must be replaced.

Sprocket. Inspect the teeth for hooking, chipping and wear. Remember a worn sprocket means rapid replacement of the driving chain which is an expensive item; the sprocket should be changed if wear is evident.

Brake Shoes. If the operating cable or rod adjustments have not been fully taken up, the brake shoe linings will be fit for further service. On the other hand, if the adjustment is completely taken up the linings must be changed; do not pack the heel of the shoe in

an endeavour to make adjustment. New linings and rivets can be purchased from your Triumph Dealer but if the owner wishes he can exchange the brake shoes for a re-conditioned set at very little extra cost. If the old brake shoes are to be used for further service, inspect the rivet heads as these must be below the surface of the lining. Rivets that show signs of contact with the brake drum can be lowered by using a suitable round punch. Support the shoe at the point where the rivet is to be knocked down.

Brake Drum. The working area should be smooth. If in rough condition due to high rivets or foreign matter, the part will have to be replaced.

Spokes. Check for slackness. If more than two or three spokes are in this condition, the wheel should be put into the hands of a competent wheel builder.

Wheel Spindles. These should spin true when placed between lathe centres or on "V" blocks.

Hub. The bearings must be a tight snug fit in the hub housing.

REAR WHEEL

REMOVAL FROM FRAME

Chain. Remove spring link and rotate the wheel until the chain is clear of the sprocket. Place a piece of rag or paper under the chain to prevent it contacting the ground.

Speedometer Cable. Disconnect at speedometer drive gearbox.

Brake Rod. Remove from cam lever.

Wheel Nuts. Slacken off nuts and disengage torque pin from anchor plate. Withdraw the wheel from the plunger fork ends.

Wheel. Tilt the machine to the left when the wheel can be withdrawn from the frame on the right hand side.

DISMANTLING

Wheel Nuts. Unscrew from the spindle.

Distance Piece (Speedometer End). Remove.

Speedometer Gearbox. Withdraw over spindle and remove the distance collar.

Anchor Plate. Hold the wheel in the vice by gripping the spindle (speedometer end); do not forget to use lead clamps to avoid damage to the thread. Ease the brake lever slightly towards the "on" position and lift anchor plate assembly complete with distance collar over the spindle.

Brake Shoes. Release the "pull off" springs when the shoes can be removed from the anchor plate. Avoid grease contact with the linings if they are to be used for further service.

Bearing Retaining Ring. This ring has a RIGHT HAND thread and to remove place a peg spanner into the diametrically opposed holes and unscrew from the hub.

Bearing (Speedometer End). Bump the opposite end of the spindle on a piece of hard wood when the bearing will be forced out of its housing complete with spindle and backing ring.

Bearing (Brake End). Drift this bearing out from the speedometer end.

Sprocket. If the teeth are not "hooked" or worn, the sprocket should be left in position and the securing bolts tested for tightness. On the other hand, if it is to be replaced, remove the 8 screws.

The wheel is now completely dismantled for examination and rectification (see page 81).




Fig. 33. REAR WHEEL. For Index see page 85

RE-ASSEMBLY OF THE WHEEL

Bearing (Brake End). Place the backing ring in the hub and then drift the bearing (well loaded with grease) into position. Screw the locking ring to the hub and well tighten with a peg spanner.

Spindle. Enter the spindle from the opposite end and ensure that the shoulder contacts the bearing now in position. Fill into the hub sufficient grease (dessert spoonful).

Bearing (Speedometer End). Lubricate the bearing and drift into position.

Sprocket. If a new sprocket is to be fitted, fit the new unit to the brake drum and ensure that the 8 screws are well tightened.

Anchor Plate. Grease the operating cam spindle and correctly position cam and lever. DO NOT be over-lavish with the grease.

Brake Shoes. Assemble these to the anchor plate in the same manner as described in page 80, "Front Wheel Assembly".

Anchor Plate Assembly. Ease brake lever towards the "on" position and then enter the brake shoes into the drum. Replace distance piece and loosely screw on the wheel retaining nut.

INDEX TO FIG. 33

<i>Index No.</i>	<i>Description.</i>	<i>Index No.</i>	<i>Description.</i>
1	Rim, rear wheel.	15	Distance piece, rear wheel spindle outer R.H.
2	Spoke, left hand (short).	16	Plate, rear brake anchor.
3	Spoke, right hand (long).	17	Cam assembly, rear brake.
4	Nipple, spoke.	18	Lever, rear brake.
5	Hub and brake drum assembly.	19	Nut, rear brake lever.
6	Sprocket, rear wheel 48T.	20	Washer, rear brake lever.
7	Bolt, rear wheel sprocket.	21	Shoe, rear brake c/w lining.
8	Washer, rear wheel sprocket.	22	Lining, rear brake.
9	Spindle, rear wheel.	23	Rivet, rear brake lining.
10	Nut, rear wheel spindle.	24	Spring, rear brake shoe.
11	Bearing, rear wheel R.H. and L.H.	25	Adjuster, rear chain.
13	Locking ring, bearing L.H.	26	Collar, rear chain adjuster.
14	Distance piece, rear wheel spindle inner R.H.	27	Nut, rear chain adjuster.
		28	Gearbox, speedometer.

Rear Wheel

Speedometer Gearbox. First lubricate the gears by using a grease gun on the nipple provided. Slide over the wheel spindle the larger of the two distance pieces, then the speedometer gearbox and finally the smaller distance piece. Loosely screw on the wheel retaining nut.




Fig. 34. FITTING THE REAR WHEEL
The Peg "A" must engage the Slot "B"

ASSEMBLING WHEEL TO FRAME

Wheel. Tilt the machine to the left and position the wheel between the plunger fork ends, chain wheel sprocket to the left. When fitting the spindle into the fork slots **MAKE SURE** that the **PEG** in the **LEFT HAND** fork engages with the **SLOT** in the brake anchor plate.

Wheel Nuts. Position the chain adjusters and tighten up the wheel nuts by hand.

Chain. Replace the chain to the sprocket—remember the closed end of the spring clip faces the direction of forward motion. Check chain tension (see page 24).

Speedometer gearbox. Fit the cable to the gearbox and screw up the cable nut.

Brake Rod. Re-connect and test brake action (see page 21).

Wheel Nuts. Screw up tightly.

TYRES

Tyre pressure should always be maintained to obtain the maximum mileage and it is advisable to make a thorough check weekly. The actual pressure at which the tyres should be maintained is more or less a matter for the rider to decide, the main factor being the weight the machine is going to carry. After inflating a tyre, always re-fit the valve cap. The cap prevents entry of dirt through the valve mechanism and forms a positive seal on the valve.

RECOMMENDED TYRE PRESSURE

TYRE SIZE—	2.75×19	3.00×19	3.25×16
	P.S.I.	P.S.I.	P.S.I.
Inflation Pressure—Front (minimum)	19	19	18
Rear („)	26	23	20

(P.S.I.—pounds per square inch)

When correcting the tyre pressure, an examination should also be made for cuts or flints and nails etc., which may have become embedded in the cover. If they are allowed to remain, no immediate damage may occur but they may at a later period, work through the cover and puncture the tube.

If the front tyre develops irregular or "stepped" wear, the tyre should be removed and the direction reversed, thereby restoring maximum resistance to tyre slip.

TWISTGRIP CONTROL

The twistgrip will require little attention other than an occasional greasing. The rotor is spring loaded in order to obtain a certain amount of frictional drag and will thus prevent the throttle closing when the hand is taken off the twistgrip to make a signal. To dismantle the twistgrip, proceed as follows:—

DISMANTLING

(SACKVILLE TYPE) TERRIER

Round Head Screws. A screw is placed at each side of the twistgrip head; unscrew these and remove the top cover.

Throttle Wire. Detach the throttle cable.

Head Grub Screws. Slacken off the three grub screws when the rotor and head can be removed from the handlebar.

(AMAL TYPE) CUB

Cable Abutment. Unscrew from the twistgrip head. To detach, pull outer casing when this abutment can be removed from the inner wire.

Head Grub Screw. Slacken the three head screws when the twistgrip can be removed from the handlebar.

Rotor. To detach rotor from the head, slacken off the friction screw when the rotor can be removed.

ASSEMBLY

Grease the handlebar section over which the rotor fits, but do not lubricate the twistgrip head otherwise the spring tension will be insufficient to hold the rotor in any position. Re-assemble the twistgrip in reverse to the dismantling procedure.

LUBRICATING CONTROL CABLES

The control cables require lubricating at intervals, as if they become dry, stiffness in operation will result. A good plan is to remove the Bowden wire connection from the lever at its top end and make a funnel with brown paper round the casing, securing it with a rubber band. Then if thin machine oil is fed into the funnel and allowed to remain over night, it will trickle down the casing and lubricate the cable. Control cables should always be kept clear of the engine as far as possible, as if they become over-heated the lubricant will be dried up.

SPARKING PLUG

The recommended gap for the type of sparking plug used in these machines is 0.022" to 0.025" (0.56 to 0.64 mm.) The plug should be cleaned periodically with a wire brush, or better still taken into a service station where it can be thoroughly cleaned in a special sparking plug cleaner. After cleaning, always check the points gap and replace the copper joint washer if it shows signs of hardness.

When the sparking plug is removed for examination, the insulator will show one of the following conditions:—

ASH WHITE—This is a sign that the plug is over-heating. Usual cause is the mixture strength too weak (a common cause being a faulty carburetter to cylinder head joint washer) or the ignition too far retarded.

DULL BLACK.—This indicates that the plug is running too cold or, in other words, the insulator is insufficiently hot to burn off the carbon. This is caused by too rich a mixture or the engine left running with a generous slow running setting (quality screw).

LIGHT BROWN—This shows that the mixture strength is correct and the engine running at the right temperature.

Sparking Plugs recommended for normal use:—**CHAMPION L.10.S**

PETROL TAP

The tap employed is the taper type and should it leak, a remedy can be made in the following manner.

Petrol Pipe. Disconnect the union nut.

Petrol Tap. Unscrew from the tank (right-hand thread).

Tap Lever. Remove the split-pin, washer, spring and back plate with the lever and spindle assembly.

Wash all the parts and smear a small quantity of very fine grinding-in paste (metal polish can be used as a substitute) on the spindle. Replace the spindle into the tap body and rotate it a few times; Remove the spindle and check the continuity of the contact surface, if unbroken, the parts should be thoroughly washed in petrol and re-assembled in the reverse manner to the dismantling sequence. Before replacing the spindle, rub the surface over with a petrol resisting grease or, if not available use tallow fat.

SPEEDOMETER DRIVE

The cable is driven by a speedometer gearbox which is attached to the rear wheel nut. If it should become necessary to replace the cable due to failure, remove the headlamp assembly and disconnect the cable at the speedometer head and then unscrew the union nut at the gearbox when the cable can be detached. The inner and outer cable can be replaced as separate items. When replacing the cable assembly to the machine, always ensure that the drive is correctly meshed before tightening the union nut.

AIR FILTER

The air filter is housed in the toolbox and battery cover unit. To remove the air filter element for cleaning or replacement the unit must be detached as a whole. To do this dismantle as follows:—

Toolbox and Battery Carrier Lid. Unscrew the knurled thumb nut and withdraw the lid.

Tools. Remove from the container.

Battery. Unscrew the strap nut and remove the strap when the battery can be withdrawn from the casing and the battery leads disconnected.

Air Filter and Casing. Remove the upper and lower nuts and withdraw the assembly. At the same time withdraw the breather pipe and carburettor rubber connection.

Air Filter Element. To remove the element unscrew the nut in the back of the casing and take off the air filter cover. Wash the element (steel gauze) in petrol until it is thoroughly clean and allow to dry. The container should also be cleaned in a similar manner.

Assembly. First oil the element using only a thin grade of oil (S.A.E.20) and then re-assemble in exactly the reverse manner described in the dismantling sequence.




Fig. 35. AIR FILTER

AMAL CARBURETTER

The Amal needle jet carburetter is fitted to these motorcycles and unless the machine is to be used for some special purpose, the standard settings should not be interfered with. These settings have been arrived at after careful experiment in order to ensure maximum efficiency and minimum fuel consumption for normal use.

During the early period of the machine's life, the carburetter should be occasionally dismantled and cleaned to remove any foreign matter which may have found its way into the float bowl or around the main and slow running jets.


Fig. 36 clearly illustrates the dismantling procedure and the adjacent index identifies the parts.

For further information see manufacturer's leaflet.

INDEX TO FIG. 36

<i>Index No.</i>	<i>Description.</i>	<i>Index No.</i>	<i>Description.</i>
1	Cable, throttle.	18	Jet, pilot.
2	Body, mixing chamber.	19	Screw, mixing chamber plug.
3	Cap, mixing chamber.	20	Washer, plug screw.
4	Spring, mixing chamber cap.	21	Holding bolt.
5	Screw, cap spring.	22	Washer, holding bolt.
6	Top, mixing chamber.	23	Body, float chamber.
7	Adjuster, throttle cable.	24	Cover, float chamber.
8	Valve, throttle.	25	Screw, float chamber cover.
9	Spring, throttle valve.	26	Float.
10	Screw, throttle adjusting.	27	Needle, float.
11	Nut, throttle adjusting screw.	28	Tickler.
12	Screw, air adjusting.	29	Spring, tickler.
13	Spring, air adjusting screw.	30	Screw, tickler spring fixing.
14	Jet, needle.	31	Locknut, needle seating.
15	Needle, jet.	32	Washer, locknut.
16	Clip, jet needle.	33	Cover nut, pilot jet.
17	Jet, main.	34	Washer, cover nut.

Fig. 36.
**THE AMAL
 CARBURETTER**
 For Index
 see page 92.



LUCAS RM13 A.C. LIGHTING AND IGNITION EQUIPMENT

GENERAL DESCRIPTION

Under NORMAL running conditions, electrical energy in the form of rectified A.C. passes through the battery from the alternator—the rate of charge depending on the position of the lighting switch. When no lights are in use, the alternator output is sufficient only to supply the ignition coil and to trickle-charge the battery. When the lighting switch is turned to the PILOT or HEAD positions, the output increases proportionately.

Under EMERGENCY starting conditions, trickle-charging continues whilst an ignition performance similar to that from a magneto is obtained. AFTER THE ENGINE HAS BEEN STARTED, NORMAL RUNNING IS RESUMED BY TURNING THE IGNITION KEY FROM "EMG" TO "IGN".

IF THE BATTERY MUST BE REMOVED, THE ENGINE CAN BE RUN WITH THE IGNITION SWITCH IN THE "EMG" POSITION PROVIDED THAT THE BATTERY NEGATIVE CABLE (BROWN) IS EARTHED TO THE FRAME. UNDER THESE CONDITIONS NO LIGHTS ARE AVAILABLE.

CIRCUIT DETAILS

The alternator stator carries three pairs of series-connected coils, one pair being permanently connected across the rectifier bridge network. The purpose of this latter pair is to provide some degree of charging current for the battery whenever the engine is running.

Connections to the remaining coils vary according to the positions of the lighting and ignition switch controls. When no lights are in use, the alternator output from the battery charging coils is regulated to a minimum by interaction of the rotor flux with the flux set up by current flowing in the short-circuited coils. In the PILOT position, these latter coils are disconnected and the regulating fluxes are consequently reduced. The alternator output therefore increases and compensates for the additional parking light load. In the HEAD position, the alternator output is further increased by the connection of all three pairs of coils in parallel.

EMERGENCY STARTING (Ignition Switch at "EMG")

With this circuit the contact breaker is arranged to open when the alternating current in the windings reaches a maximum.

When current flows and the contacts are closed, the main return circuit to the alternator is through one arm of the rectifier bridge. At the instant of contact separation, the built-up energy of the alternator windings quickly discharges through an alternative circuit provided by the battery and the ignition coil primary winding. This rapid transfer of energy from alternator to coil, causes H.T. to be induced in the ignition coil secondary winding and a spark to occur at the plug.

Since, with the ignition switch at "EMG" and the engine running, the battery receives a charging current, the battery voltage soon begins to rise. This rising voltage opposes the alternator voltage and gradually effects a reduction in the energy available for transfer to the coil. In the event of a rider omitting to return the ignition key from position "EMG" to position "IGN", this reduction in spark energy will cause misfiring to occur and will remind the rider to switch over to normal running.

As previously mentioned, continuous running without a battery is readily arranged by earthing the cable normally connected to the battery negative terminal.

CONSTRUCTION

The alternator consists essentially of a spigot-mounted and bolted 6-coil laminated stator with a centre-bored rotor carried on, and driven by, an extension to the crankshaft. The rotor has an hexagonal steel core, each face of which carries a high-energy permanent magnet keyed to a laminated pole tip. The pole tips are riveted circumferentially to brass side plates, the assembly being cast in aluminium and machined to give a smooth external finish. The stator and rotor can be separated without any need to fit magnet keepers to the rotor poles.

RATING

The alternator is designed for use with headlamp bulbs not exceeding 30-watts rating (or equivalent Continental touring bulbs which, although of higher wattage rating, are yet suitable due to the generally higher average road speeds encountered abroad).

MAINTENANCE OF ELECTRICAL EQUIPMENT

THE ALTERNATOR

Except for an occasional inspection of the snap-connectors in the three green output cables—these connectors must be clean and tight—the alternator requires no maintenance.

IGNITION COIL

The ignition coil should be kept clean, particularly between the terminals, and the terminal connections kept tight.

CONTACT BREAKER UNIT

Lubrication: every 3,000 miles

- (i) Remove the metal cover and lightly smear the surface of the cam with one of the greases recommended for grease gun use in the "Recommended Lubricants" chart in the instruction book. If this is not available, clean engine oil may be used.

WARNING

When carrying out the above lubrication, no oil or grease must be allowed to get onto or near the contacts.

- (ii) Lubricate the automatic timing control mechanism, using thin machine oil.

Cleaning: every 6,000 miles

Remove the metal cover and wipe it inside and outside with a clean dry fluffless cloth.

Examine the Contact Breaker. The contacts must be free from grease or oil. If they are burned or blackened, clean with fine carborundum stone or very fine emery cloth, afterwards wiping away any dirt or metal dust with a clean petrol-moistened cloth.

Cleaning of the contacts should be carried out with the moving contact removed. To do this, unscrew the capacitor securing screw, remove the terminal nut and withdraw the nylon washer. The assembly, comprising capacitor, terminal and contact breaker spring arm, can now be lifted out of the unit body.

Note: When refitting this assembly, see that the widest edge of the nylon terminal block is at the top.

CONTACT BREAKER SETTING

The contact breaker setting should be checked after the first 500 miles running and subsequently every 6,000 miles. To check the gap, turn the engine over slowly until the contacts are seen to be fully open and insert a 0.014-0.016 in. feeler gauge between the contacts.

If the gap width is correct, the gauge will be a sliding fit. If the gap width varies appreciably from the gauge thickness, the setting must be adjusted. To do this, keep the engine in the position giving maximum contact opening and slacken the screw at the side of the unit body.

Slide the fixed contact carrier in its slotted hole, until the correct gap is obtained. Retighten the screw.

HIGH TENSION

If the high tension cable shows signs of perishing or cracking it should be replaced, using 7 mm. rubber covered ignition cable. To do this, remove the metal washer and moulded nut from the defective cable. Thread the new cable through the moulded nut and bare the conductor for about $\frac{1}{4}$ in. Pass the exposed strands through the metal washer and bend the strands back radially. Refit the moulded nut into the h.t. terminal.

LIGHTING EQUIPMENT

HEADLAMPS

Headlamps fitted to machines intended for the Home Market and for Export excluding Europe and the U.S.A. These lamps have a main double filament prefocus 6-volt 30/24 watt Lucas No. 312 bulb, together with a parking light 6-volt 3 watt Lucas No. 988 bulb. A window inserted in the main reflector provides illumination for the speedometer.

Headlamps fitted to machines intended for Export to Europe.

These lamps have a main double filament prefocus 6-volt 35/35 watt Lucas No. 403 bulb, together with one parking light bulb and one speedometer light bulb, each of the latter being Lucas No. 988 6-volt 3 watt bulbs.

Headlamps fitted to machines intended for Export to the U.S.A. These lamps have a main double filament prefocus 6-volt 30/24 watt Lucas No. 312 bulb, together with a speedometer light 6-volt 3 watt Lucas No. 988 bulb.

Basically, the above lamps are identical, the differences occurring only in connection with the method of speedometer illumination and parking light illumination. The following notes apply to all three headlamps.

REPLACING THE HEADLAMP BULB

To gain access to the headlamp bulb, slacken the front rim retaining screw, situated at the bottom of the rim. Disengage and withdraw the front rim and Light Unit assembly, removing the lower edge first. Press the moulded adaptor inwards and turn it to the left. Lift off the adaptor and withdraw the defective bulb. When inserting a replacement bulb, locate the slot in the bulb flange with the projection in the bulb holder.

Refit the adaptor, engaging its moulded recesses with corresponding projections on the bulb holder. Press inwards and secure by turning the adaptor to the right. Refit the outer rim to the nacelle, locating the top of the rim first. After replacing, check the beam setting.

SETTING THE HEADLAMP BEAM

To check the headlamp beam setting, stand the motorcycle in front of a light coloured wall at a distance of about 25 feet. The machine should be carrying its normal load during this check, since the

weight of the rider (and pillion passenger) may affect the setting. Switch on the main beam. This should be directed straight ahead and parallel with the ground. If it is not, adjust the rim securing screw, turning the screw to the right to lower the beam, and vice versa. With the Lucas prefocus type bulbs fitted in these lamps, the filament is correctly positioned during manufacture in relation to the focal point of the reflector. No further focusing is necessary.

REPLACING THE PARKING LIGHT BULB (when fitted)

Disengage and withdraw the front rim and Light Unit assembly. The parking light bulb holder and bulb can then be withdrawn from the reflector in which it is a push-fit.

REPLACING THE SPEEDOMETER LIGHT BULB (when fitted)

Disengage and withdraw the front rim and Light Unit assembly. The speedometer light bulb can then be withdrawn from its holder which is built on to the main bulb adaptor.

INSTRUMENT NACELLE

This unit is held to the lower nacelle by 6 screws and nuts which must first be removed before disconnecting the various cables which are attached. When the screws have been removed, disconnect the lighting cables at the connectors, then detach the speedometer cable. The unit can now be left attached to the gear indicator control cable. If the operator wishes to remove the complete unit, detach the indicator cable wire from the indicator rack and pinion. Refit in reverse manner.

REAR LIGHTING

Access to rear light bulbs is gained by removing the two moulded cover retaining screws. The correct replacements are as follows:—

- Rear Lights only: Lucas No. 988 6 volt 3 watt bulb
- Stop Tail Lights: Lucas No. 384 6/18 watt bulb.

Ignition Fault Finding

Bulb No. 384 has offset securing pins to prevent incorrect insertion into the bulb holder and to ensure that the higher wattage filament is illuminated when the brake pedal is depressed.

THE BATTERY

Once a month, or more often in hot climates, check the level of the electrolyte in the cells. If necessary, add distilled water to bring the electrolyte level with the top edges of the separators. Keep the battery top clean and dry, and the vent holes in the filler plugs clear. Naked lights should not be brought near to the battery, as the gas given off is explosive.

Occasionally check the battery condition with an hydrometer. These checks should not be made immediately after topping up, as the electrolyte will not be thoroughly mixed.

Specific gravity readings and their indication:—

1.280-1.300	Cell fully charged
About 1.210	Cell about half discharged
Below 1.150	Cell fully discharged

IGNITION FAULT FINDING

BEFORE SEARCHING FOR AN IGNITION FAULT, ALWAYS CHECK OVER ALL ELECTRICAL CONNECTIONS, CLEAN AND TIGHTEN IF NECESSARY.

ENGINE WILL NOT START

NO SPARK AT PLUG

Note: To check, remove the plug and place it on the cylinder head after re-fitting the connector. Turn the ignition switch to "IGN" (clockwise) and kick over the engine. The plug should fire with a blue spark. If there is no spark, turn switch to "EMG" (anti-clockwise) and test again.

Plug Oily, Fouled or Faulty. Clean thoroughly, preferably in a plug cleaning machine, re-set the points gap to .020"-.025" and re-fit. Replace with correct grade plug if faulty.

Distributor, Coil or Condenser Faulty.

DISTRIBUTOR. See that the cover is properly fitted and the clip secure. Check the gap of the contact breaker points and clean and adjust if necessary (see pages 96 and 97).

COIL. First clean the coil, particularly between the cable connections. To check the low tension circuit, connect a volt meter between the coil terminal marked "CB" and earth. If there is no reading with the ignition switched on there is a fault in the coil primary winding. If this test shows that the low tension primary circuit is in order, remove the H.T. lead from the plug and take off the connector. Take off the distributor cap and rotate the engine until the contact points are closed. Switch on the ignition and hold the end of the H.T. lead about a $\frac{1}{4}$ " from the cylinder block. Flick the contact points open with the finger and a spark should pass from the H.T. lead. No spark indicates a fault in the H.T. winding. Any fault in a coil can only be corrected by fitting a new unit.

CONDENSER. To test the condenser, switch on the ignition and connect a volt meter across the open contacts. If there is no reading, remove the condenser and re-test. If a reading on the meter is then obtained, the condenser is faulty and should be changed.

ENGINE WILL NOT START WITH SWITCH AT "IGN"; BUT STARTS ON "EMG".

Battery discharged due to short circuit, poor condition due to age or damage, prolonged use for parking or low rate of charge from alternator. Have battery charged from external source and equipment checked by an authorised Lucas Agent or Triumph Dealer as soon as possible.

ENGINE RUNS WITH SWITCH AT "IGN"; BUT NOT ON "EMG".

Examine leads and connections from ignition switch to coil, and from coil to distributor. Check distributor contacts and ignition timing (see page 57). If the machine will still not run in "EMG" switch position, have the equipment checked by an authorised Lucas Agent or Triumph Dealer.

ROUGH RUNNING AND MISFIRING WITH SWITCH AT "IGN".

Check earth connection for battery and wiring of switch and rectifier.

TO INCREASE BATTERY CHARGING RATE

When a machine is continually ridden at low speeds, the rate of charge with the lighting switch in the "OFF" position may be insufficient to keep the battery fully charged. In such cases the charge rate may be increased by removing the wire on the switch connecting terminals numbered 5 and 6. Number 6 is still connected to number 18, but this wire should not be interfered with. The numbers 5 and 6 are marked on the switch casing adjacent to the respective terminals.




Fig. 37.
 LUCAS WIRING DIAGRAM FOR RM13 LIGHTING AND IGNITION

CLEANING THE MOTORCYCLE

A clean motorcycle not only gives pride of ownership, but also assists the owner in maintaining the machine in first class condition.

Never at any time attempt to remove road dirt when the machine is dry, this should always be washed off with water. There are on the market at present, a number of extremely good cleaning solvents for removing oil and road dirt from the exterior of the machine, and they can be obtained through most accessory dealers. The preparation should be applied with a 1" paint brush to the machine and a little time allowed to elapse in order that the solution can penetrate the oily surfaces. The machine should be in a dry condition before commencing this operation. Now wash off the solution with water from a watering can; the reason the latter is advised is so that the operator can direct a controlled stream of water, thus avoiding trouble such as water in the brakes, ignition system and fuel system. After completion, dry off the machine with a chamois leather and when completely dry, finish off with a good polish, of which there are numerous makes available.

TOOLKIT

The toolkit supplied with the machine will enable the owner to carry out minor adjustments and replacements. Special tools for dismantling such units as the cylinder head, rear suspension and timing gear etc. can be made available on application to the nearest Triumph Dealer.




Fig. 38. TOOLKIT

RECOMMENDED LUBRICANTS UNITED KINGDOM

UNIT	ESSO	MOBIL	SHELL	BP ENERGOL	WAKEFIELD	CODE
Engine—Summer ... Winter ...	Essolube 30 Essolube 20	Mobiloil A Mobiloil Arctic	Shell X-100 30 Shell X-100 20/20W	Energol SAE 30 Energol SAE 20	Castrol XL Castrolite	A
Gearbox ...	Essolube 30	Mobiloil A	Shell X-100 30	Energol SAE 30	Castrol XL	B
Primary Chaincase	Essolube 20	Mobiloil Arctic	Shell X-100 20/20W	Energol SAE 20	Castrolite	C
Telescopic Fork ... Rear Suspension ... Wheels ... Steering Races ...	Esso Grease	Mobilgrease No. 2	Shell Retinax A or RB	Energol C3	Castrolase Heavy	D
Easing Rusted Parts	Esso Penetrating Oil	Mobil Spring Oil	Shell Donax P	Energol Penetrating Oil	Castrol Penetrating Oil	

The above lubricants have been carefully tested and found to give satisfactory results with the Terrier and Tiger Cub.

RECOMMENDED LUBRICANTS OVERSEAS

UNIT	ESSO	MOBIL	SHELL	BP ENERGOL	WAKEFIELD	CODE
Engine Above 90° F. 32°-90° F. ... Below 32° F.	Esso Motor Oil 40 Esso Motor Oil 30 Esso Motor Oil 20W	Mobiloil A.F. Mobiloil A Mobiloil Arctic	Shell X-100 40 Shell X-100 30 Shell X-100 20/20W	Energol Motor Oil SAE 40 Energol Motor Oil SAE 30 Energol Motor Oil SAE 20W	Castrol XXL Castrol XL Castrolite	A
Gearbox ...	Esso Motor Oil 30	Mobiloil A	Shell X-100 30	Energol Motor Oil SAE 30	Castrol XL	B
Primary Chaincase	Esso Motor Oil 20W	Mobiloil Arctic	Shell X-100 20/20W	Energol Motor Oil SAE 20W	Castrolite	C
Telescopic Fork ... Rear Suspension ... Wheels ... Steering Races ...	Esso Grease	Mobilgrease No. 2	Shell Retinax A or RB	Energol Grease C3	Castrol Heavy	D
Easing Rusted Parts	Esso Penetrating Oil	Mobil Spring Oil	Shell Donax P.	Energol Penetrating Oil	Castrol Penetrating Oil	

The above lubricants have been carefully tested and found to give satisfactory results with the Terrier and Tiger Cub.




Fig. 39. LUBRICATION CHART

Figures in circles refer to right-hand side of machine and those in squares to the left-hand side not visible in the illustration.

The Lubricant Code Reference is on Pages 106 and 107

No.	Part	Lubrication Code	No.	Part	Lubrication Code
1	Brake Cam	D	7	Rear Suspension	D
2	Wheel Hubs	D	8	Speedometer Gearbox	D
3	Steering Races	D	9	Air Filter	C
4	Primary Chaincase	C	10	Engine Oil Tank	A
5	Gearbox	B	11	Cables (Exposed)	D
6	Brake Pedal Spindle	D		" (Internal)	C




Fig. 40. NEW TYPE CLUTCH COMPONENTS.

Index No.	Description.	Index No.	Description.
1	Plate, backing.	8	Pin, backing plate.
2	Rubber, rebound.	9	Ball, sprocket bearing.
3	Rubber, drive.	10	Ring, sprocket bearing.
4	Spider.	11	Sprocket and housing.
5	Lock washer.	12	Plate, driven (plain).
6	Centre.	13	Plate, driving (bonded).
7	Cup, centre driving.	14	Plate, pressure.
		15	Locknut, adjuster.
		16	Adjuster, pressure plate.
		17	Cup, spring.
		18	Spring, pressure.
		19	Nut, pressure spring.

NEO-LANGITE CLUTCH

Machines with the following engine numbers 11621 to 11822
12152 to 12222
12704 onwards

have been fitted with a clutch employing Neo-Langite friction material, which is bonded to the steel plates.

The bonded plates and sprocket and housing must not be placed in a "trike" vat as boiling trichlorethylene attacks the bonding. The linings are not affected by petrol, oil or paraffin. The thickness of the bonded driving plates over the lining is $\frac{1}{8}$ ", the thickness of the lining being $\frac{1}{32}$ ". Provided that the linings are not charred or peeling from the plate and there is no metal-to-metal contact due to wear, the plates are suitable for further use.

CLUTCH SHOCK ABSORBER SERVICING INSTRUCTIONS

Machines from engine number 16515 have the pins (Fig. 40, Ref. 8) riveted over, and if it becomes necessary to dismantle the unit, the pins and backplate (Fig. 40, Ref. 1) will be unfit for further service due to the damage to the threads. When re-assembling a shock absorber unit, screw the pins fully home, turn the unit over and rivet over the protruding portion of the pins.

SPECIAL NOTE

As a number of parts have been re-designed, machines up to engine number 16514 requiring individual shock absorber parts should fit carton pack CP.152 consisting of:—

T1345 Shock absorber assembly. T1347 Tab Washer.
T1119 Key, spider to mainshaft. T1348 Nut, clutch securing.

LUBRICATION SYSTEM AUXILIARY BALL VALVES

From engine number 10197 two auxiliary ball valves have been fitted in the lubrication system of the Terrier and Tiger Cub models, in order to reduce the possibility of lubrication failure if foreign matter enters the system. The springs are situated in the two holes in the crankcase into which the oil pump delivers, with the balls seating on the oil pump body.




Fig. 41. Oil Pump showing Auxiliary Ball Valves.

To assemble the pump to the crankcase, first mate the balls to the seating by giving each a sharp tap with a metal drift. Then lift the balls and put a slight smear of Vaseline underneath to retain them in position. Grease the paper joint washer and place it in position on the crankcase and insert the two springs into the holes.

Then place the oil pump driving link over the eccentric driving peg, and carefully place the pump in position so that the balls are in the correct position on top of the springs. Insert the two retaining bolts and washers and tighten.

It is advisable to make this modification to earlier machines, when the engine is stripped for overhaul. Full instructions are contained in Service Bulletin No. 132, obtainable on request, the cost of the modification being negligible.

ILLUSTRATION INDEX

<i>Fig.</i>		<i>Page</i>
1	Control Layout	10
2	Lubrication Diagram	15
3	Oil Pump in Position	17
4	Checking Tappet Clearance	20
5	Front Brake Adjustment	22
6	Rear Brake Adjustment	23
7-12	Chain Repairs	25
13-14	Chain Rivet Extractor	26
15	Supporting the Piston	31
16	Positioning the Push Rods	32
17	Engine and Gearbox Unit	36
18	Flywheel Parting and Assembly Tool	43
19	Removing the Driving Side Flywheel	45
20	Removing the Crankpin	45
21	Replacing the Crankpin	47
22	Fitting the Timing Side Flywheel	47
23	Aligning the Flywheels	48
24	Valve Timing	50
25	The Mainshaft and Layshaft Gear Cluster	52
26	View of the Gear and Selector Mechanism	53
27	Kickstarter Spring in Position	54
28	Clutch Components	61
29	Shock Absorber Unit	64
30	Telescopic Fork	66
31	Rear Suspension	75
32	Front Wheel	78
33	Rear Wheel	84
34	Fitting Rear Wheel	86
35	Air Filter	91
36	Carburetter	93
37	Wiring Diagram (RM13)	103
38	Toolkit	105
39	Lubrication Chart	108
40	New Type Clutch Components	110
41	Oil Pump showing Auxiliary Ball Valves	112

INDEX OF CONTENTS

	<i>Page</i>
A. Adjusting the Brakes	22
Adjusting the Steering Head Races	65
Air Filter	90
C. Carburetter (Amal)	92
Changing the Oil	19
Changing the Fork Springs	65
Chain Adjustment	24
Cleaning the Motor Cycle	104
Clutch	58
Clutch (New Type)	111
Clutch Shaft Shock Absorber	63
Controls	11
D. Decarbonising	29
Dismantling the Engine and Gearbox Unit	35
F. Front Wheel	77
I. Ignition Timing	56
Ignition Fault Finding	100
L. Lighting and Ignition Equipment	94
Lighting Equipment	97
Lubrication System	14
Lubricating Control Cables	89
Lubrication Chart Index	108 & 109
M. Maintenance of Lubrication System	16
Maintenance of Electrical Equipment	96
O. Oil Pump	17
Oil Pump Auxiliary Ball Valves	112
Overhauling the Engine and Gearbox Unit	34